

How to read this list:	
Mark	Description
√	Function is supported.
*	Newly added function or modified

V30/PC-MAX Function List													
Automaker:				Mercedes-Benz									
Software Version:				V8.2									
Brand	Region	Year	Model	Vehicle Type	ECU Type	System	ECU Supplier	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
Mercedes	All	1998-2004	A-Class	168	Drive	ECM - Engine control monolith		√	√	√	√	√	
						CDI - Common Rail Diesel Injection		√	√	√	√	√	
						ACS - Automatic clutch system		√	√	√	√	√	
						FTC - Front transmission control		√	√	√	√	√	Control module adaptations Diagnosis routiness
						GRM - Gear recognition module		√	√	√	√	√	
					Chassis	ESP - Electronic stability program		√	√	√	√		
						Body	AB - Airbag		√	√	√	√	
					LCP - Lower control panel			√	√	√	√	√	
					ATA - Anti-theft alarm system			√	√	√	√	√	
					RFL - Radio frequency locking/electric central locking			√	√	√	√	√	
					Information and Communication	ICM - Instrument cluster with maintenance interval display		√	√	√	√	√	
						PTS - Parktronic system		√	√	√	√	√	Read coding and change if necessary
						D2B - AUDIO		√	√	√	√	√	Read coding and change if necessary
						CDC - CD changer		√	√	√			
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		√	√	√			
					Seats and doors	APS - Auto pilot system		√	√	√			
						DCM-FL - Door control module front left		√	√	√	√	√	
						DCM-FR - Door control module front right		√	√	√	√	√	
						DCM-RL - Door control module rear left		√	√	√	√	√	
					Air Conditioning	DCM-RR - Door control module rear right		√	√	√	√	√	
						HEAT/TAC - Automatic heater + PTC heater booster/Automatic temperature control		√	√	√	√	√	

Mercedes	All	2004-2005	A-Class	169	Conditioning	STH/HB - Stationary heater/Heater booster	✓	✓	✓	✓	✓	
					Drive	ESM - Electronic selector module	✓	✓	✓	✓	✓	Read coding and change if necessary
						FCVT - Continuously variable automatic transmission	✓	✓	✓	✓		
						ME-SFI - Motor electronics	✓	✓	✓	✓	✓	
						CDI - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program	✓	✓	✓	✓		
						ES - Electrical power steering	✓	✓	✓	✓		
					Body	AB - Airbag	✓	✓	✓	✓		
						CGW - Central gateway	✓	✓	✓			
						EIS - Electronic ignition switch(Without Keyless Go)	✓	✓	✓	✓		
						HRA-FR - Front right headlamp range control	✓	✓	✓	✓		
						HRA-FL - Front left headlamp range control	✓	✓	✓	✓	✓	
						OCP - Overhead control panel	✓	✓	✓	✓		
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module	✓	✓	✓			
						On-board electrical system(voltage supply)	✓	✓	✓	✓		
						ATA - Anti-theft alarm system	✓	✓	✓	✓	✓	
					Information and communication	IC - Instrument cluster	✓	✓	✓	✓	✓	
						ASSYST Active Service System	✓	✓	✓	✓		AssystSetting
						ASSYST PLUS - PLUS Active Service System	✓	✓	✓	✓		General servicing Control unit adaptations
						SCM - Steering column module	✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system	✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND	✓	✓	✓	✓	✓	
						CDC - CD changer	✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓	✓	
						CTEL - Telephone adapter for portable CTEL	✓	✓	✓	✓		
					Seats and	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
DCM-FR - Door control module front right	✓	✓	✓	✓		✓						

Mercedes	All	2005-2009	A-Class	169	Doors	DCM-RL - Door control module rear left	✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right	✓	✓	✓	✓	✓	
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning	✓	✓	✓	✓	✓	
						ESM - Electronic selector module	✓	✓	✓	✓	✓	Read coding and change if necessary
					Drive	FCVT - Continuously variable automatic transmission	✓	✓	✓	✓		
						ME-SFI - Motor electronics	✓	✓	✓	✓	✓	
						CDI - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
						ESP - Electronic stability program	✓	✓	✓	✓		
					Chassis	ES - Electrical power steering	✓	✓	✓	✓		
						Body	AB - Airbag	✓	✓	✓	✓	
					EIS - Electronic ignition switch(Without Keyless Go)		✓	✓	✓			
					HRA-FR - Front right headlamp range control		✓	✓	✓	✓		
					HRA-FL - Front left headlamp range control		✓	✓	✓	✓		
					OCP - Overhead control panel		✓	✓	✓	✓	✓	
					UCP - Upper control panel		✓	✓	✓	✓		
					SAM - Signal acquisition and actuation module		✓	✓	✓	✓	✓	
					AHE - Trailer recognition		✓	✓	✓	✓	✓	
					SVMCM - Special vehicle multifunction control module		✓	✓	✓	✓	✓	
					On-board electrical system(voltage supply)		✓	✓	✓			
					ATA - Anti-theft alarm system		✓	✓	✓	✓		
					Information and communication		ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓
						SCM - Steering column module	✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system	✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND	✓	✓	✓	✓	✓	
						CDC - CD changer	✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓	✓	
						CTEL - Telephone adapter for portable CTEL	✓	✓	✓	✓		
					Seats and	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
DCM-FR - Door control module front right	✓	✓	✓	✓		✓						

					Doors	DCM-RL - Door control module rear left	✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right	✓	✓	✓	✓	✓	
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning	✓	✓	✓	✓	✓	
Mercedes	All	2005	B-Class	245	Drive	ESM - Electronic selector module	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDI - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
						FCVT - Continuously variable automatic transmission	✓	✓	✓	✓		
						ME-SFI - Motor electronics	✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program	✓	✓	✓	✓		
						ES - Electrical power steering	✓	✓	✓	✓		
					Body	AB - Airbag	✓	✓	✓	✓		
						CGW - Central gateway	✓	✓	✓			
						EIS - Electronic ignition switch(Without Keyless Go)	✓	✓	✓	✓		
						XALWA-L - Xenon headlamp,left	✓	✓	✓	✓		
						XALWA-R - Xenon headlamp,right	✓	✓	✓	✓		
						OCP - Overhead control panel	✓	✓	✓	✓		
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module	✓	✓	✓			
						On-board electrical system(voltage supply)	✓	✓	✓	✓		
						ATA - Anti-theft alarm system	✓	✓	✓	✓	✓	
					Information and communication	IC - Instrument cluster	✓	✓	✓	✓	✓	
						ASSYST Active Service System	✓	✓	✓	✓		
ASSYST PLUS - PLUS Active Service System	✓	✓	✓	✓								
SCM - Steering column module	✓	✓	✓	✓		✓	Initial startup					
PTS - Parktronic system	✓	✓	✓	✓		✓						
AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	✓	✓	✓	✓		✓						
COMAND/AUDIO - Audio50 or COMAND	✓	✓	✓	✓		✓						
CDC - CD changer	✓	✓	✓	✓								
TV - TV tuner(Not valid for Japan and USA)	✓	✓	✓	✓		✓						

					CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓			
				Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓		
					DCM-FR - Door control module front right		✓	✓	✓	✓	✓		
					DCM-RL - Door control module rear left		✓	✓	✓	✓	✓		
					DCM-RR - Door control module rear right		✓	✓	✓	✓	✓		
				Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning		✓	✓	✓	✓	✓		
Mercedes	All	2005-2009	B-Class	245	Drive	ESM - Electronic selector module		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDI - Common Rail Diesel Injection		✓	✓	✓	✓	✓	
						FCVT - Continuously variable automatic transmission		✓	✓	✓	✓		
						ME-SFI - Motor electronics		✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓		
						ES - Electrical power steering		✓	✓	✓	✓		
					Body	AB - Airbag		✓	✓	✓	✓		
						CGW - Central gateway		✓	✓	✓			
						EIS - Electronic ignition switch(Without Keyless Go)		✓	✓	✓	✓		
						XALWA-L - Xenon headlamp,left		✓	✓	✓	✓		
						XALWA-R - Xenon headlamp,right		✓	✓	✓	✓		
						OCP - Overhead control panel		✓	✓	✓	✓		
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						SAM - Signal acquisition and actuation module		✓	✓	✓	✓	✓	
						AHE - Trailer recognition		✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module		✓	✓	✓			
						On-board electrical system(voltage supply)		✓	✓	✓	✓		
						ATA - Anti-theft alarm system		✓	✓	✓	✓	✓	
					Information and communication	IC - Instrument cluster		✓	✓	✓	✓	✓	
						ASSYST Active Service System		✓	✓	✓	✓		
ASSYST PLUS - PLUS Active Service System		✓	✓	✓		✓							
SCM - Steering column module		✓	✓	✓		✓	✓	Initial startup					
PTS - Parktronic system		✓	✓	✓		✓	✓						
AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)		✓	✓	✓		✓	✓						
COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓		✓	✓						

						CDC - CD changer		✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓		
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning		✓	✓	✓		✓	
<b>Mercedes</b>	All	1984-1993	C-CLASS	201	Body	AB		✓	✓	✓	✓		
<b>Mercedes</b>	All	1994-1996	C-CLASS	202	Drive	HFM		✓	✓	✓	*		
						ME2		✓	✓	✓	✓		
						PMS		✓	✓	✓	✓		
						ERE		✓	✓	✓	✓		
					Chassis	ABS		✓	✓	✓	✓		
						ASR		✓	✓	✓	✓		
						ETS		✓	✓	✓	✓		
						ESP		✓	✓	✓	✓		
						BAS		✓	✓	✓	✓		
						EGS		✓	✓	✓	✓	✓	
					Body	RCL(DAS1/X)		✓	✓	✓	✓		
						RCL(DAS2/X)		✓	✓	✓	✓		
						ATA		✓	✓	✓	✓		
						AB		✓	✓	✓	✓		
						KI		✓	✓	✓	✓	✓	
						LWR		✓	✓	✓	✓		
Air conditioning	TAC		✓	✓	✓								
					Drive	ETC - Electronic transmission control		✓	✓	✓	✓	✓	
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						HFM-SFI - Hot film engine management		✓	✓	✓	✓		
						ME2-SFI - Motor electronics		✓	✓	✓	✓		
						CDI - Common Rail Diesel Injection		✓	✓	✓	✓	✓	
						IFI - Electronic in-line injection system diesel/DFI - Electronic distributor injection system diesel		✓	✓	✓	✓	✓	

Mercedes	All	1997-2000	C-CLASS	202	Chassis	Traction systems ABS,ASR,ETS,ESP		√	√	√	√	√	Road test Learning processes Resetting of variant locking
						BAS - Brake assist		√	√	√	√		
					Body	AB - Airbag		√	√	√	√	Read coding and change if necessary Coded vehicle data	
						OCP - Overhead control panel		√	√	√	√	√	
						EIS - Electronic ignition switch / KG - keyless Go(Special equipment)		√	√	√	√		
						PSE - Pneumatic system equipment		√	√	√	√	Variant coding	
						SAM - Signal acquisition and actuation module		√	√	√	√		
						LCP - Lower control panel		√	√	√	√		
						HRA - Headlamp rage adjustment		√	√	√	√		
						SVMCM - Special vehicle multifunction control module		√	√	√			
					Information and communication	ICM - Instrument cluster with maintenance interval display		√	√	√	√	√	Setting
						SCM - Steering column module(AS of model year 2002)		√	√	√	√	√	Initial startup
						PTS - Parktronic system		√	√	√	√	√	
						D2B - COMAND or AUDIO		√	√	√	√	√	Read coding and change if necessary
						CDC - CD changer		√	√	√			
						VCS - Voice control system		√	√	√			
						SOUND - Sound system		√	√	√			
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		√	√	√			
						TELE AID,E-call or cellular telephone - Emergency call system(K-wire)		√	√	√	√	√	
						DN - Dynamic navigation by means of CTEL(K-wire)		√	√	√			
						APS - Auto pilot system		√	√	√			
						SDAR - Satellite radio(USA)		√	√	√	√	√	
					Seats and Doors	DCM1 - Door control module front driver side		√	√	√	√		
						DCM2 - Door control module front passenger side		√	√	√	√		
						DCM3 - Door control module rear driver side		√	√	√	√		
						DCM4 - Door control module rear passenger side		√	√	√	√		
						ESA-FL - Electric seat adjustment front left		√	√	√	√		
						ESA-FR - Electric seat adjustment front right		√	√	√	√		
					Air conditioning	TAC - Automatic temperature control/AAC - Automatic air conditioning		√	√	√	√		Read coding and change if necessary

Mercedes	All	2001-2003	C-CLASS	203	STH - Stationary heater with remote control		✓	✓	✓				
					Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit	
					Drive	ESM - Electronic selector module		✓	✓	✓	✓	✓	
						DTR - Distronic		✓	✓	✓	✓		Control unit adaptations
						ME-SFI - Motor electronics		✓	✓	✓	✓		
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
						CDI2 - Common Rail Diesel Injection 2		✓	✓	✓	✓	✓	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff
						CDI3 - Common Rail Diesel Injection 3		✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	
						BAS - Brake assist		✓	✓	✓	✓	✓	
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number
						OCP - Overhead control panel		✓	✓	✓	✓	✓	Setting of limit position of excess force limiter
						EIS - Electronic ignition switch		✓	✓	✓	✓		
						HRA-FL - Front left headlamp range control		✓	✓	✓	✓		
						HRA-FR - Front right headlamp range control		✓	✓	✓	✓	✓	Zero position adjustment
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						UCP - Upper control panel		✓	✓	✓	✓	✓	Control unit adaptations
						SAM-F - Signal acquisition and actuation module front		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	Control unit adaptations
						AHE - Trailer recognition		✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module		✓	✓	✓			
					Information and	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	✓
						SCM - Steering column module(AS of model year 2002)		✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			



				air communication	VCS - Voice control system	√	√	√	√		
					SOUND - Sound system	√	√	√			
					CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	√	√	√			
					TELE AID,E-call or cellular telephone - Telematic system(K-wire)	√	√	√	√		
					TV - TV tuner(Not valid for Japan)	√	√	√	√		
				Seats and Doors	DCM-FL - Door control module front left	√	√	√	√	√	
					DCM-FR - Door control module front right	√	√	√	√	√	
					DCM-RL - Door control module rear left	√	√	√	√	√	
					DCM-RR - Door control module rear right	√	√	√	√	√	
					ESA driver - Electric seat adjustment front passenger(with memory)	√	√	√	√	√	
					ESA passenger - Electric seat adjustment front passenger(with memory)	√	√	√	√	√	
				Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning	√	√	√	√	√	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
					STH - Stationary heater with remote control	√	√	√	√	√	
				Drive	Transmission	√	√	√	√	√	Initial startup Control unit adaptations Adaptations Diagnosis routiness
					ESM - Electronic selector module	√	√	√	√	√	Read coding and change if necessary
					ME-SFI - Motor electronics	√	√	√	√		
					ME-SFI 2.8 - Motor electronics 2.8	√	√	√	√	√	
					ME 9.7 - Motor electronics 9.7	√	√	√	√	√	
					CDI2 - Common Rail Diesel Injection 2	√	√	√	√	√	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff
					CDI3 - Common Rail Diesel Injection 3	√	*	√	√	√	
				CDI4 - Common Rail Diesel Injection 4	√	√	√	√	√		
				Chassis	ESP - Electronic stability program	√	√	√	√	√	Road test Erase zero point offset error of component N49(steering angle sensor)
					CGW - Central gateway	√	√	√			
					EIS - Electronic ignition switch / KG - keyless Go(Special equipment)	√	√	√	√		
					AB - Airbag	√	√	√	√		Read coding and change if necessary Chassis number

Mercedes	All	2004-2007	C-CLASS	203	Body	WSS - Weight sensing system(USA)		√	√	√			
						SAM-F - Signal acquisition and actuation module front		√	√	√	√	√	
						REAR SAM - Rear signal acquisition and actuation module		√	√	√	√	√	
						HRA-FL - Front left headlamp range control		√	√	√	√		
						HRA-FR - Front right headlamp range control		√	√	√	√	√	Zero position adjustment
						OCP - Overhead control panel		√	√	√	√	√	Read coding and change if necessary
						LCP - Lower control panel		√	√	√	√	√	
						UCP - Upper control panel		√	√	√	√	√	
						System diagnosis		√	√	√	√		
						AHE - Trailer recognition		√	√	√	√	√	
						On-board electrical system(voltage supply)		√	√	√	√		
						Information and communication	ICM - Instrument cluster with maintenance interval display		√	√	√	√	√
					SCM[MRM] - Steering column module			√	√	√	√	√	Initial startup
					PTS - Parktronic system			√	√	√	√	√	
					AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)			√	√	√	√	√	
					COMAND/AUDIO - Audio50 or COMAND			√	√	√	√	√	Read coding and change if necessary
					CDC - CD changer			√	√	√	√		
					TV - TV tuner(Not valid for Japan and USA)			√	√	√	√	√	
					CTEL - Telephone adapter for portable CTEL			√	√	√	√		
					VCS - Voice control system			√	√	√			
					SOUND - Sound system			√	√	√			
					Seats and Doors	TELE AID,E-call or cellular telephone - Telematic system(K-wire)		√	√	√	√	√	
						DCM-FL - Door control module front left		√	√	√	√	√	Read coding and change if necessary Normalize left power window
						DCM-FR - Door control module front right		√	√	√	√	√	
						DCM-RL - Door control module rear left		√	√	√	√	√	
						DCM-RR - Door control module rear right		√	√	√	√	√	
						ESA driver - Electric seat adjustment front passenger(with memory)		√	√	√	√	√	
					Air conditioning	ESA passenger - Electric seat adjustment front passenger(with memory)		√	√	√	√	√	
						C-AAC/AAC/HEAT - Convenience automatic air conditioning		√	√	√	√	√	

					STH - Stationary heater with remote control		√	√	√	√			
Mercedes	All	2009	CLC	203	Drive	Transmission		√	√	√	√		
						ESM - Electronic selector module		√	√	√	√	√	
						ME-SFI - Motor electronics		√	√	√	√	√	
						ME 9.7 - Motor electronic 9.7		√	√	√	√	√	
						CDI D2 - Common Rail Diesel Injection( Chassis CAN bus )		√	√	√	√	√	
					Chassis	ESP - Electronic stability program		√	√	√	√	√	
						Body	EIS - Electronic ignition switch		√	√	√	√	
					AB - Airbag			√	√	√	√		
					SAM-F - Signal acquisition and actuation module front			√	√	√	√	√	
					REAR SAM - Rear signal acquisition and actuation module			√	√	√	√	√	
					XALWA-L - Xenon headlamp,left( Front end CAN bus )			√	√	√	√	√	
					XALWA-R - Xenon headlamp,right( Front end CAN bus )			√	√	√	√	√	
					OCP - Overhead control panel			√	√	√	√	√	
					LCP - Lower control panel			√	√	√	√	√	
					UCP - Upper control panel			√	√	√	√	√	
					On-board electrical system(voltage supply)			√	√	√	√		
					Information and communication	ICM - Instrument cluster with maintenance interval display		√	√	√	√	√	
						SCM[MRM] - Steering column module		√	√	√	√	√	
						PTS - Parktronic system		√	√	√	√	√	
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)		√	√	√	√	√	
						COMAND/AUDIO - Audio50 or COMAND		√	√	√	√	√	
						CDC - CD changer		√	√	√	√		
						TV - TV tuner(Not valid for Japan and USA)		√	√	√	√	√	
CTEL - Telephone adapter for portable CTEL		√	√	√									
VCS - Voice control system		√	√	√									
SOUND - Sound system		√	√	√									
TELE AID,E-call or cellular telephone - Telematic system(K-wire)		√	√	√	√								
DCM-FL - Door control module front left		√	√	√	√	√							

					Seats and Doors	DCM-FR - Door control module front right		√	√	√	√	√		
						ESA driver - Electric seat adjustment front passenger(with memory)		√	√	√	√	√		
						ESA passenger - Electric seat adjustment front passenger(with memory)		√	√	√	√	√		
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning		√	√	√	√	√		
						STH - Stationary heater with remote control		√	√	√	√			
					Drive	ME-SFI - Motor electronics( Chassis CAN bus )		√	√	√	√	√		
						ME 9.7 - Motor electronics 9.7( Chassis CAN bus )		√	√	√	√	√		
						CDI D - Common Rail Diesel Injection( Chassis CAN bus )		√	√	√	√	√		
						CDI D2 - Common Rail Diesel Injection( Chassis CAN bus )		√	√	√	√	√		
						CDI 6 - Common Rail Diesel Injection( Chassis CAN bus )		√	√	√	√	√		
						FSCU - Fuel Pump( Drive train CAN bus )		√	√	√	√	√		
						Transmission		√	√	√	√	√		
						ESM - Electronic selector module( Drive train CAN bus )		√	√	√	√	√		
					Chassis	ABR - Adaptive Brake( Chassis CAN bus )		√	√	√	√			
						Suspension( Chassis CAN bus )		√	√	√	√	√		
						TPC - Tire pressure monitor( Interior CAN bus )		√	√	√	√	√		
					Body	CGW - Central gateway( Central CAN bus )		√	√	√	√			
						EZS - Electronic ignition switch( Interior CAN bus )		√	√	√	√			
						KG - Keyless Go( Interior CAN bus )		√	√	√				
						XALWA-L - Xenon headlamp,left( Front end CAN bus )		√	√	√	√	√		
						XALWA-R - Xenon headlamp,right( Front end CAN bus )		√	√	√	√	√		
						AB - Airbag		√	√	√	√			
						WSS - Weight sensor system (USA)( Interior CAN bus )		√	√	√				
						System 'Dr-side SAM' with connected LIN components( Interior CAN bus )		√	√	√	√	√		
						System 'REAR SAM' with connected LIN components( Interior CAN bus )		√	√	√	√	√		
						OCP - Overhead control panel( Interior CAN bus )		√	√	√	√	√		

Mercedes	All	2008-2009	C-CLASS	204	COU[ZBE] - Central operating unit( Telematic CAN bus )		√	√	√	√	√		
					RevETR-LF - Left front reversible emergency tensinoing retrator( Chassis CAN bus )		√	√	√	√			
					RevETR-RF - Right front reversible emergency tensinoing retrator( Chassis CAN bus )		√	√	√	√			
					Information and communication	ICM - Instrument cluster with maintenance interval display( Interior CAN bus )		√	√	√	√	√	confirm overall maintenance
						SCM[MRM] - Steering column module( Chassis CAN bus )		√	√	√	√	√	
						PTS - Parktronic( Interior CAN bus )		√	√	√	√	√	
						RFK - Backup camera Janpan( Interior CAN bus)		√	√	√	√		
						COMAND - COMAND with integral telematics gateway(MOST network management, diagnosis gateway)		√	√	√	√	√	
						Tuner - Radio tuner with amplifier		√	√	√			
						CTEL - Mobile telephone adapter with universal interface		√	√	√	√	√	
						VCS - Voice control(Linguatronic)		√	√	√	√	√	
						TV - TV tuner(Not valid for Japan and USA)		√	√	√	√		
						SDAR - Satellite radio (Valid for USA)		√	√	√	√	√	
						ZAN - Central Display		√	√	√	√	√	
						COU[ZBE] - Central operating unit( Telematic CAN bus )		√	√	√	√	√	
					Seats and Doors	KBE-H -Rear A/C operating unit		√	√	√			
						System 'Door control module front left' with connected LIN components( Interior CAN bus )		√	√	√	√	√	
						System 'Door control module front right' with connected LIN components( Interior CAN bus )		√	√	√	√	√	
						DCM-RL - Door control module rear left( Interior CAN bus )		√	√	√	√	√	
						DCM-RR - Door control module rear right( Interior CAN bus )		√	√	√	√	√	
						ESA driver - Electric seat adjustment driver( Interior CAN bus )		√	√	√	√	√	
					Air conditioning	AAC - Automatic air conditioning( Interior CAN bus )		√	√	√	√	√	

Mercedes	All	1998-2002	CLK	208	Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						HFM-SFI - Hot film engine management	✓	✓	✓	✓		
						ME2-SFI - Motor electronics	✓	✓	✓	✓	✓	
					Chassis	Traction systems ABS,ASR,ETS,ESP	✓	✓	✓	✓	✓	
						BAS - Brake assist	✓	✓	✓	✓	✓	
						VP-Vacuum pump braker booster	✓	✓	✓	✓	✓	
					Body	AB - Airbag	✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						OCP - Overhead control panel	✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch ELCODE	✓	✓	✓	✓	✓	
						PSE -Pneumatic system equipment	✓	✓	✓	✓	✓	Variant coding
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓		
						LCP - Lower control panel	✓	✓	✓	✓		
						HRA - Headlamp range adjustment	✓	✓	✓	✓	✓	
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	Clock Reset odometer to 0 km Oil change
						D2B - COMAND or AUDIO	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer	✓	✓	✓			
						VCS - Voice control system	✓	✓	✓			
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	✓	✓	✓			
						APS - Auto pilot system	✓	✓	✓			
						PTS - Parktronic system	✓	✓	✓	✓	✓	
						TELE AID,E-call or cellular telephone - Telematic system(K-wire)	✓	✓	✓			
						DN - Dynamic navigation by means of CTEL(K-wire)	✓	✓	✓			
TV - TV tuner	✓	✓	✓									
Seats and Doors	DCM1 - Door control module front driver side	✓	✓	✓	✓	✓						
	DCM2 - Door control module front passenger side	✓	✓	✓	✓	✓						

					ESAS	ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓		
						ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓		
					Air conditioning	TAC-Automatic temperature control/AAC - Automatic air conditioning		✓	✓	✓	✓	✓	Variant coding
						STH - Stationary heater		✓	✓	✓	✓	✓	
Mercedes	All	2003-2004	CLK	209	Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						DTR - Distronic		✓	✓	✓	✓		Control unit adaptations
						ME-SFI - Motor electronics		✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
						CDI2 - Common Rail Diesel Injection		✓	✓	✓	✓	✓	Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test Erase zero point offset error of component N49(steering angle sensor)
						Body	AB - Airbag		✓	✓	✓	✓	
					OCP - Overhead control panel			✓	✓	✓	✓	Setting of limit position of excess force limiter	
					EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)			✓	✓	✓	✓		
					HRA-FL - Front left headlamp range control			✓	✓	✓	✓		
					HRA-FR - Front right headlamp range control			✓	✓	✓	✓	Zero position adjustment	
					LCP - Lower control panel			✓	✓	✓	✓		
					UCP - Upper control panel			✓	✓	✓	✓	Control unit adaptations	
					SAM-F - Signal acquisition and actuation module front			✓	✓	✓	✓		
					REAR SAM - Rear signal acquisition and actuation module			✓	✓	✓	✓		
					RVC - Rollover bar soft top control module			✓	✓	✓	✓		
					AHE - Trailer recognition		✓	✓	✓	✓			
						ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	
						SCM - Steering column module(AS of model year 2002)		✓	✓	✓	✓	initial startup	

					Information and communication	PTS - Parktronic system		✓	✓	✓	✓	✓		
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓		
						CDC - CD changer		✓	✓	✓				
						VCS - Voice control system		✓	✓	✓				
						SOUND - Sound system		✓	✓	✓	✓			
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		✓	✓	✓	✓			
						TELE-AID,E-call or cellular telephone - Telematic system (K-wire)		✓	✓	✓				
						TV - TV tuner(Not valid for Japan)		✓	✓	✓				
					Seats and Doors	DCM-L - Door control module left		✓	✓	✓	✓	✓		
						DCM-R - Door control module right		✓	✓	✓	✓	✓		
						ESA driver - Electric seat adjustment front passenger(with memory)		✓	✓	✓	✓	✓		
						ESA passenger - Electric seat adjustment front passenger(with memory)		✓	✓	✓	✓	✓		
					Air conditioning	C-AAC/AAC/HEAT - Convenience automatic air conditioning		✓	✓	✓	✓	✓		Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
					Drive	Transmission		✓	✓	✓	✓	✓		Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module		✓	✓	✓	✓	✓		
						ME-SFI - Motor electronics		✓	✓	✓	✓			
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓		
						ME9.7-Motor electronics 9.7		✓	✓	✓	✓	✓		
						ME9.7(AMG) - Motor electronics 9.7(AMG)		✓	✓	✓	✓	✓		
						CDI2 - Common Rail Diesel Injection		✓	✓	✓	✓	✓		Adjustment On temperature of heater booster(Electric heater booster) Injector classification/Injector shutoff
						CDI3 - Common Rail Diesel Injection 3		✓	✓	✓	✓	✓		
						CDI4 - Common Rail Diesel Injection 4		✓	✓	✓	✓	✓		
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓		Road test





Mercedes	All	1984-1995	E-CLASS	124	Drive	DM(Diagntic Module)		✓	✓	✓	✓							
						EFP		✓	✓	✓	✓	✓						
						TPM		✓	✓	✓	✓	✓						
						ISC		✓	✓	✓	✓	✓						
					Chassis	EAG		✓	✓	✓	✓	✓						
						Body	RCL(DAS1/X)		✓	✓	✓	✓						
					RCL(DAS2/X)			✓	✓	✓	✓							
ATA(Anti-Theft Alarm)		✓	✓	✓	✓													
AB(Air bag)		✓	✓	✓	✓													
Mercedes	All	1984-1995	E-CLASS	124 034/036	Drive	LH1		✓	✓	✓	✓							
						DM(Diagntic Module)		✓	✓	✓	✓							
						EFP		✓	✓	✓	✓	✓						
						TPM		✓	✓	✓	✓	✓						
						ISC		✓	✓	✓	✓	✓						
						GM		✓	✓	✓	✓							
					Chassis	ASR		✓	✓	✓	✓							
						ABS		✓	✓	✓	✓							
					Body	ATA(Anti-Theft Alarm)		✓	✓	✓	✓							
						AB(Air bag)		✓	✓	✓	✓							
						RCL(DAS1)		✓	✓	✓	✓							
										Drive	HFM		✓	✓	✓	✓		
											ME2		✓	✓	✓	✓		
ME1RE		✓	✓	✓							✓							
DM		✓	✓	✓							✓							
EVE		✓	✓	✓							✓	✓						
EFP		✓	✓	✓							✓	✓						
TPM		✓	✓	✓							✓	✓						
ISC		✓	✓	✓							✓	✓						
Chassis	ABS		✓	✓						✓	✓							
	ASR		✓	✓						✓	✓							
	ETS		✓	✓						✓	✓							
	ESP		✓	✓						✓	✓							
	BAS		✓	✓						✓	✓							
	ADS		✓	✓						✓	✓							

Mercedes	All	1996-1997	E-CLASS	210	Body	EGS	✓	✓	✓	✓	✓		
						EAG	✓	✓	✓	✓	✓		
						PML	✓	✓	✓	✓			
						RFL	✓	✓	✓	✓			
						RCL(DAS1/X)	✓	✓	✓	✓			
						RCL(DAS2/X)	✓	✓	✓	✓			
						KFB	✓	✓	✓	✓			
						PSE	✓	✓	✓	✓			
						ATA	✓	✓	✓	✓			
						AB	✓	✓	✓	✓			
						KI	✓	✓	✓	✓	✓		
						PTS	✓	✓	✓	✓	✓		
						LWR	✓	✓	✓	✓			
						APS	✓	✓	✓				
						Audio,COMMAND	✓	✓	✓	✓	✓		
						Tele-AID	✓	✓	✓				
						CDC	✓	✓	✓	✓	✓		
						E-Call	✓	✓	✓	✓	✓		
						SKF	✓	✓	✓	✓	✓		
						Air conditioning	Air Conditioning	✓	✓	✓	✓	✓	
							STH	✓	✓	✓	✓	✓	
						Drive	Transmission	✓	✓	✓	✓	✓	
							ESM - Electronic selector module	✓	✓	✓	✓	✓	Initial startup
							HFM-SFI - Hot film engine management	✓	✓	✓	✓		
							ME2-SFI - Motor electronics	✓	✓	✓	✓		
							IFI- Electronic in-line injection system diesel/DFI- Electronic distributor injection system diesel	✓	✓	✓	✓		
							CDI - Common Rail Diesel Injection	✓	✓	✓	✓		
Chassis	ABS	✓	✓	✓	✓		✓						
	ASR	✓	✓	✓	✓		✓	Road test Learning processes Resetting of variant locking					
	ETS	✓	✓	✓	✓		✓						
	ESP	✓	✓	✓	✓		✓						
	ADS - Adaptive damping system	✓	✓	✓	✓								

Mercedes	All	1998-2002	E-CLASS	210	BAS - Brake assist		✓	✓	✓	✓			
					VP - Vacuum pump brake booster		✓	✓	✓	✓	✓		
					SPS - Speed-sensitive power steering		✓	✓	✓				
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch ELCODE		✓	✓	✓	✓		
						PSE - Pneumatic system equipment		✓	✓	✓	✓		Variant coding
						SAM - Signal acquisition and actuation module		✓	✓	✓	✓		
						LCP - Lower control panel		✓	✓	✓	✓		
						HRA - Headlamp range adjustment		✓	✓	✓	✓		
						SVMCM - Special vehicle multifunction control module		✓	✓	✓			
					Information and communication	ICM - Instrument cluster		✓	✓	✓	✓	✓	Clock Reset odometer to 0 km Oil change
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓	✓	✓	
						VCS - Voice control system		✓	✓	✓			
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		✓	✓	✓			
						APS - Auto pilot system		✓	✓	✓			
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						TELE AID,E-call or cellular telephone		✓	✓	✓	✓	✓	
						DN - Dynamic navigation by means of CTEL(K-wire)		✓	✓	✓			
						TV - TV tuner		✓	✓	✓			
					Seats and Doors	DCM1 - Door control module front driver side		✓	✓	✓	✓		
						DCM2 - Door control module front passenger side		✓	✓	✓	✓		
						DCM3 - Door control module rear driver side		✓	✓	✓	✓		
						DCM4 - Door control module rear passenger side		✓	✓	✓	✓		
						ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓		
						ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓		
Air conditioning	TAC - Automatic temperature control/AAC - Automatic air conditioning		✓	✓	✓	✓		Read coding and change if necessary					
	STH - Stationary heater		✓	✓	✓								



Mercedes	All	2005	E-CLASS	211	BCM - Battery control module		✓	✓	✓	✓	✓			
					AHE - Trailer recognition		✓	✓	✓	✓	✓	✓	✓	
					SVMCM - Special vehicle multifunction control		✓	✓	✓					
					On-board electrical system (voltage supply)		✓	✓	✓	✓				
					Information and communication	IC - Instrument cluster		✓	✓	✓	✓	✓		
						ASSYST Active Service System		✓	✓	✓	✓		AssystSetting	
						ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations	
						SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	Initial startup	
						PTS - Parktronic system		✓	✓	✓	✓	✓		
						AGW - Audio gateway		✓	✓	✓	✓	✓		
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary	
						NAVI - Navigation(Only in combination with COMAND)(Not valid for Japan)		✓	✓	✓	✓	✓		
						CDC - CD changer		✓	✓	✓	✓			
						HFS - Hands free system and microphone		✓	✓	✓				
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓		
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓	✓		
						MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal		✓	✓	✓				
						Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-FR - Door control module front right			✓	✓	✓	✓	✓	Read coding and change if necessary	
					DCM-RL - Door control module rear left			✓	✓	✓	✓	✓	Read coding and change if necessary	
					DCM-RR - Door control module rear right			✓	✓	✓	✓	✓	Read coding and change if necessary	
					ESA driver - Electric seat adjustment driver			✓	✓	✓	✓	✓		
					ESA passenger - Electric seat adjustment FR. Pass.			✓	✓	✓	✓	✓		
					DS-LF - Left front dynamic seat			✓	✓	✓	✓	✓		
					DS-RF - Right front dynamic seat			✓	✓	✓	✓	✓		
					DSP - Pneumatic pump for dynamic seat			✓	✓	✓	✓	✓		
					TLC - Trunk lid control			✓	✓	✓	✓	✓		
					HS - Seat heater			✓	✓	✓				
					Air conditioning	C-AAC - Convenience automatic air conditioning		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors	
						STH - Stationary heater with remote control		✓	✓	✓	✓	✓		

					HSW - Heated steering wheel		✓	✓	✓	✓	✓	
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
					ESM - Electronic selector module		✓	✓	✓	✓	✓	Read coding and change if necessary
					DTR - Distronic		✓	✓	✓	✓	✓	
					ME-SFI - Motor electronics		✓	✓	✓	✓		
					ME-SFI 2.8- Motor electronics 2.8		✓	✓	✓	✓	✓	
					ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓	Learning of the throttle valve stop
					CDI 3 - Common Rail Diesel Injection 3		✓	✓	✓	✓	✓	
					CDI 4 - Common Rail Diesel Injection 4		✓	✓	✓	✓	✓	
					CDI 5 - Common Rail Diesel Injection 5		✓	✓	✓	✓	✓	
			Chassis	SBC - Sensotronic Brake Control		✓	✓	✓	✓		Deactive system Active system bleed brake system Control unit adaptations	
				ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test	
				Suspension		✓	✓	✓	✓	✓	Initial startup	
				TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Initial startup Control unit adaptations	
			Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number	
				WSS - Weight sensor system		✓	✓	✓				
				RevETR-LF - Left front revesible emergency tensioning retractor		✓	✓	✓	✓			
				RevETR-RF - Right front revesible emergency tensioning retractor		✓	✓	✓	✓			
				CGW - Central gateway		✓	✓	✓				
				EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)		✓	✓	✓	✓	✓		
				HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors	
				OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panornamic sliding roof	
				UCP - Upper control panel		✓	✓	✓	✓	✓		
			LCP - Lower control panel		✓	✓	✓	✓	✓			
			Dr-side SAM - Dr. signal acquisition and actuation		✓	✓	✓	✓	✓			

Mercedes	All	2005-2006	E-CLASS	211	Pass-side SAM - Pass-side signal acquisition and actuation		✓	✓	✓	✓	✓		
					REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓		
					System diagnosis		✓	✓	✓	✓			
					BCM - Battery control module		✓	✓	✓	✓	✓		
					AHE - Trailer recognition		✓	✓	✓	✓	✓		
					SVMCM - Special vehicle multifunction control		✓	✓	✓				
					On-board electrical system (voltage supply)		✓	✓	✓	✓			
					Information and communication	IC - Instrument cluster		✓	✓	✓	✓	✓	
						ASSYST Active Service System		✓	✓	✓	✓		AssystSetting
						ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations
						SCM[MRRM] - Steering column module		✓	✓	✓	✓	✓	
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						AGW - Audio gateway		✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary
						NAVI - Navigation(Only in combination with COMAND)(Not valid for Japan)		✓	✓	✓	✓	✓	
						CDC - CD changer		✓	✓	✓	✓		
						HFS - Hands free system and microphone		✓	✓	✓			
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓	✓	
						MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal		✓	✓	✓			
						Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓
					DCM-FR - Door control module front right			✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-RL - Door control module rear left			✓	✓	✓	✓	✓	Read coding and change if necessary
					DCM-RR - Door control module rear right			✓	✓	✓	✓	✓	Read coding and change if necessary
					ESA driver - Electric seat adjustment driver			✓	✓	✓	✓	✓	
					ESA passenger - Electric seat adjustment FR. Pass.			✓	✓	✓	✓	✓	
					DS-LF - Left front dynamic seat			✓	✓	✓	✓	✓	
					DS-RF - Right front dynamic seat			✓	✓	✓	✓	✓	
					DSP - Pneumatic pump for dynamic seat			✓	✓	✓	✓	✓	
					TLC - Trunk lid control			✓	✓	✓	✓	✓	
					HS - Seat heater		✓	✓	✓				





Mercedes	All	2006-2008	E-CLASS	211	UCP - Upper control panel		√	√	√	√	√		
					LCP - Lower control panel		√	√	√	√	√		
					Dr-side SAM - Dr. signal acquisition and actuation		√	√	√	√	√		
					Pass-side SAM - Pass-side signal acquisition and actuation		√	√	√	√	√		
					REAR SAM - Rear signal acquisition and actuation module		√	√	√	√	√		
					System diagnosis		√	√	√	√			
					AHE - Trailer recognition		√	√	√	√	√		
					SVMCM -Special vehicle multifunction control		√	√	√				
					On-board electrical system (voltage supply)		√	√	√	√	√		
					Information and communication	IC - Instrument cluster		√	√	√	√	√	
						ASSYST Active Service System		√	√	√	√		AssystSetting
						ASSYST PLUS - PLUS Active Service System		√	√	√	√		General servicing Control unit adaptations
						SCM[MRM] - Steering column module		√	√	√	√	√	
						PTS - Parktronic system		√	√	√	√	√	
						AGW - Audio gateway		√	√	√	√	√	
						COMAND/AUDIO - Audio50 or COMAND		√	√	√	√	√	Read coding and change if necessary
						NAVI - Navigation(Only in combination with COMAND)(Not valid for Japan)		√	√	√	√	√	
						CDC - CD changer		√	√	√	√		
						HFS - Hands free system and microphone		√	√	√			
						TV - TV tuner(Not valid for Japan and USA)		√	√	√	√	√	
						CTEL - Telephone adapter for portable CTEL		√	√	√	√	√	
						MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal		√	√	√			
						Seats and Doors	DCM-FL - Door control module front left		√	√	√	√	√
					DCM-FR - Door control module front right			√	√	√	√	√	Read coding and change if necessary
					DCM-RL - Door control module rear left			√	√	√	√	√	Read coding and change if necessary
					DCM-RR - Door control module rear right			√	√	√	√	√	Read coding and change if necessary
					ESA driver - Electric seat adjustment driver			√	√	√	√	√	
					ESA passenger - Electric seat adjustment FR. Pass.			√	√	√	√	√	
					DS-LF - Left front dynamic seat			√	√	√	√	√	
					DS-RF - Right front dynamic seat			√	√	√	√	√	
DSP - Pneumatic pump for dynamic seat		√	√	√	√		√						

					TLC - Trunk lid control		✓	✓	✓	✓	✓		
					HS - Seat heater		✓	✓	✓				
				Air conditioning	C-AAC - Convenience automatic air conditioning/AAC		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors	
					STH - Stationary heater with remote control		✓	✓	✓	✓	✓		
					HSW - Heated steering wheel		✓	✓	✓	✓	✓		
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness	
						ESM - Electronic selector module		✓	✓	✓	✓	✓	Read coding and change if necessary
						DTR - Distronic		✓	✓	✓	✓		Control module adaptations
						ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓	
						ME 9.7(AMG) - Motor electronics 9.7(AMG)		✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
						CDI 4 - Common Rail Diesel Injection 4		✓	✓	✓	✓	✓	
				Chassis	SBC - Sensotronic Brake Control		✓	✓	✓	✓		Deactive system Active system bleed brake system Control unit adaptations	
						ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test
						AIRmatic		✓	✓	✓	✓	✓	Initial startup
						TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Initial startup Control unit adaptations
				Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number	
						WSS - Weight sensor system (USA)		✓	✓	✓			
						RevETR-LF - Left front reversible emergency tensinoing retrator		✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tensinoing retrator		✓	✓	✓	✓		
						CGW - Central gateway		✓	✓	✓			
						EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)		✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors

Mercedes	All	2005	CLS	219	Body	OCP - Overhead control panel		√	√	√	√	√	Read coding and change if necessary Panoramic sliding roof
						UCP - Upper control panel		√	√	√	√	√	
						LCP - Lower control panel		√	√	√	√	√	
						Dr-side SAM - Dr. signal acquisition and actuation		√	√	√	√	√	
						Pass-side SAM - Pass-side signal acquisition and actuation		√	√	√	√	√	
						REAR SAM - Rear signal acquisition and actuation module		√	√	√	√	√	
						System diagnosis		√	√	√	√		
						BCM - Battery control module		√	√	√	√	√	
						On-board electrical system (voltage supply)		√	√	√	√	√	
					Information and communication	IC - Instrument cluster		√	√	√	√		
						ASSYST Active Service System		√	√	√	√		AssystSetting
						ASSYST PLUS - PLUS Active Service System		√	√	√	√		General servicing Control unit adaptations
						SCM[MRM] - Steering column module		√	√	√	√	√	Initial startup
						PTS - Parktronic system		√	√	√	√	√	
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)		√	√	√	√	√	
						COMAND/AUDIO - Audio50 or COMAND		√	√	√	√	√	Read coding and change if necessary
						CDC - CD changer		√	√	√	√		
						TV - TV tuner(Not valid for Japan and USA)		√	√	√	√	√	
						CTEL - Telephone adapter for portable CTEL		√	√	√	√		
					Seats and Doors	DCM-FL - Door control module front left		√	√	√	√	√	Read coding and change if necessary
						DCM-FR - Door control module front right		√	√	√	√	√	Read coding and change if necessary
						DCM-RL - Door control module rear left		√	√	√	√	√	Read coding and change if necessary
						DCM-RR - Door control module rear right		√	√	√	√	√	Read coding and change if necessary
						ESA driver - Electric seat adjustment driver(with memory)		√	√	√	√	√	
						ESA passenger - Electric seat adjustment FR. Pass.(with memory)		√	√	√	√	√	
						DS-LF - Left front dynamic seat		√	√	√	√	√	
						DS-RF - Right front dynamic seat		√	√	√	√	√	
						DSP - Pneumatic pump for dynamic seat		√	√	√	√	√	
						TLC - Trunk lid control		√	√	√	√	√	
					HS - Seat heater		√	√	√	√	√		

					Air conditioning	C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
						STH - Stationary heater with remote control	✓	✓	✓	✓	✓	
						HSW - Heated steering wheel	✓	✓	✓	✓	✓	
					Drive	Transmission	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						DTR - Distronic	✓	✓	✓	✓		
						ME 9.7 - Motor electronics 9.7	✓	✓	✓	✓	✓	
						ME 9.7(AMG) - Motor electronics 9.7(AMG)	✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
						CDI 4 - Common Rail Diesel Injection 4	✓	✓	✓	✓	✓	
					Chassis	SBC - Sensotronic Brake Control	✓	✓	✓	✓		Deactive system Active system bleed brake system Control unit adaptations
						ESP - Electronic stability program	✓	✓	✓	✓	✓	Road test
						AIRmatic	✓	✓	✓	✓	✓	Initial startup
						TPC - Tire pressure monitor	✓	✓	✓	✓	✓	Initial startup Control unit adaptations
					Body	AB - Airbag	✓	✓	✓	✓		Read coding and change if necessary Chassis number
						WSS - Weight sensor system (USA)	✓	✓	✓			
						RevETR-LF - Left front reversible emergency tensinoing retrator	✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tensinoing retrator	✓	✓	✓	✓		
						CGW - Central gateway	✓	✓	✓			
						EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)	✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment	✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
						OCP - Overhead control panel	✓	✓	✓	✓	✓	Read coding and change if necessary Panornamic sliding roof
					UCP - Upper control panel	✓	✓	✓	✓	✓		

Mercedes	All	2005-2006	CLS	219	LCP - Lower control panel		✓	✓	✓	✓	✓		
					Dr-side SAM - Dr. signal acquisition and actuation		✓	✓	✓	✓	✓		
					Pass-side SAM - Pass-side signal acquisition and actuation		✓	✓	✓	✓	✓		
					REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓		
					System diagnosis		✓	✓	✓	✓			
					BCM - Battery control module		✓	✓	✓	✓	✓		
					On-board electrical system (voltage supply)		✓	✓	✓	✓	✓		
					Information and communication	IC - Instrument cluster		✓	✓	✓	✓		
						ASSYST Active Service System		✓	✓	✓	✓		AssystSetting
						ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations
						SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)		✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓		
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	Read coding and change if necessary
						ESA driver - Electric seat adjustment driver(with memory)		✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment FR. Pass.(with memory)		✓	✓	✓	✓	✓	
						DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
						DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
						DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓	
						TLC - Trunk lid control		✓	✓	✓	✓	✓	
					HS - Seat heater		✓	✓	✓	✓	✓		

					Air conditioning	C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
						STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
						HSW - Heated steering wheel		✓	✓	✓	✓	✓	
					Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						DTR - Distronic		✓	✓	✓	✓	✓	
						ME 9.7		✓	✓	✓	✓	✓	
						ME 9.7(AMG)		✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
						CDI 4 - Common Rail Diesel Injection 4		✓	✓	✓	✓	✓	
				Chassis	ABR - Adaptive Brake		✓	✓	✓	✓	✓		
					Suspension		✓	✓	✓	✓	✓	Initial startup	
					TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Initial startup Control unit adaptations	
				Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number	
					WSS - Weight sensor system (USA)		✓	✓	✓				
					RevETR-LF - Left front reversible emergency tensinoing retrator		✓	✓	✓	✓			
					RevETR-RF - Right front reversible emergency tensinoing retrator		✓	✓	✓	✓			
					CGW - Central gateway		✓	✓	✓				
					EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)		✓	✓	✓	✓	✓		
					HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors	
					OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panoramic sliding roof	
					UCP - Upper control panel		✓	✓	✓	✓	✓		
					LCP - Lower control panel		✓	✓	✓	✓	✓		
				Dr-side SAM - Dr. signal acquisition and actuation		✓	✓	✓	✓	✓			

Mercedes	All	2006-2009	CLS	219	Pass-side SAM - Pass-side signal acquisition and actuation		✓	✓	✓	✓	✓		
					REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓		
					System diagnosis		✓	✓	✓	✓			
					BCM - Battery control module		✓	✓	✓	✓	✓		
					On-board electrical system (voltage supply)		✓	✓	✓	✓	✓		
					Information and communication	IC - Instrument cluster		✓	✓	✓	✓		
						ASSYST Active Service System		✓	✓	✓	✓		AssystSetting
						ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations
						SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)		✓	✓	✓	✓	✓	
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓	✓		
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓		
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	Read coding and change if necessary
						DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	Read coding and change if necessary
						ESA driver - Electric seat adjustment driver(with memory)		✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment FR. Pass.(with memory)		✓	✓	✓	✓	✓	
						DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
						DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
						DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓	
						TLC - Trunk lid control		✓	✓	✓	✓	✓	
						HS - Seat heater		✓	✓	✓	✓	✓	
					Air conditioning	C-AAC - Convenience automatic air conditioning/AAC		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
						STH - Stationary heater with remote control		✓	✓	✓	✓	✓	



						HSW - Heated steering wheel		✓	✓	✓	✓	✓	
<b>Mercedes</b>	All	1984-1991	S-CLASS	126	Body	AB		✓	✓	✓	✓		
					Drive	HFM		✓	✓	✓	✓		
						ME2		✓	✓	✓	✓		
						ME1RE		✓	✓	✓	✓		
						ME1LI		✓	✓	✓	✓		
						LH1		✓	✓	✓	✓		
						LH2		✓	✓	✓	✓		
						DM		✓	✓	✓	✓		
						ERE		✓	✓	✓	✓		
						EFP		✓	✓	✓	✓		
						TPM		✓	✓	✓	✓		
						ISC		✓	✓	✓	✓		
						GM		✓	✓	✓	✓		
						Chassis	ABS		✓	✓	✓	✓	
					ASR			✓	✓	✓	✓		
					ETS			✓	✓	✓	✓		
					ESP			✓	✓	✓	✓		
					BAS			✓	✓	✓	✓		
					ADS			✓	✓	✓	✓		
					EGS			✓	✓	✓	✓	✓	
					EAG			✓	✓	✓	✓	✓	
					PML		✓	✓	✓	✓			
					Body	RFL		✓	✓	✓	✓		
						RCL(DAS1/X)		✓	✓	✓	✓		
						RCL(DAS2/X)		✓	✓	✓	✓		
						KFB		✓	✓	✓	✓		
						PSE		✓	✓	✓	✓		
						ATA		✓	✓	✓	✓		
						AB		✓	✓	✓	✓		
						KI		✓	✓	✓	✓	✓	
						PTS		✓	✓	✓	✓	✓	
						LWR		✓	✓	✓	✓		
					APS		✓	✓	✓				

					Audio,COMMAND		✓	✓	✓			
					Tele-AID		✓	✓	✓			
					CDC		✓	✓	✓			
					E-Call		✓	✓	✓			
					ICS		✓	✓	✓			
				Air conditioning	Air Conditioning		✓	✓	✓	✓		
					STH		✓	✓	✓			
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
					ESM - Electronic selector module		✓	✓	✓	✓	✓	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.
					DTR - Distronic		✓	✓	✓	✓		Control unit adaptations
					ME2- SFI - Motor electronics		✓	✓	✓	✓	✓	
					ME- SFI 2.7 - Motor electronics 2.7		✓	✓	✓	✓	✓	
					CDI 3- Common Rail Diesel Injection 3		✓	✓	✓	✓		
					CDI-V - Common Rail Diesel Injection		✓	✓	✓	✓		
				Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking
					Suspension-Airmatic		✓	✓	✓	✓	✓	Initial startup Level calibration
					TPC - Tire pressor monitor		✓	✓	✓	✓	✓	Control unit adaptations
					ABC - ABC active body control		✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
					AB - Airbag		✓	✓	✓	✓	✓	Read coding and change if necessary Coded vehicle data
					OCP - Overhead control panel		✓	✓	✓	✓	✓	Setting of limit position of excess force limiter Read coding and change if necessary
					EIS - Electronic ignition switch ELCODE(DAS 3)		✓	✓	✓	✓	✓	
					HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	
					UCP - Upper control panel		✓	✓	✓	✓	✓	

Mercedes	All	2000-2003	S-CLASS	220	Body	PSE - Pneumatic system equipment		✓	✓	✓	✓	✓	Lower or raise head restraints Read coding and change if necessary
						SAM-FL - Front left signal acquisition and actuation module		✓	✓	✓	✓	✓	
						SAM-FR - Front right signal acquisition and actuation module		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
						AHE - Trailer recognition		✓	✓	✓	✓	✓	Control unit adaptations
						KG - Keyless Go		✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module		✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	ASSYST settings
						SCM - Steering column module		✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓			
						SOUND - Sound system		✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		✓	✓	✓			
						TV - TV tuner		✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic system(K-wire)		✓	✓	✓	✓	✓	
						DN - Dynamic navigation by means of CTEL(K-wire)		✓	✓	✓			
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	
						ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓	
						ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓	
						ESA-R - Electric seat adjustment rear		✓	✓	✓		✓	
						OSB-FL - Multicontour backrest front left		✓	✓	✓	✓	✓	
						OSB-FR - Multicontour backrest front right		✓	✓	✓	✓	✓	
						OSB-R - Multicontour backrest rear		✓	✓	✓	✓		
					AAC - Automatic air conditioning		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary	

					Air conditioning	REAR AC - Rear air conditioning		✓	✓	✓	✓	✓	
					Air conditioning	STH - Stationary heater(Up to 05/2000)		✓	✓	✓	✓	✓	
					Air conditioning	STH - Stationary heater(As of 05/2000)		✓	✓	✓	✓	✓	
					Air conditioning	HSW - Heated steering wheel		✓	✓	✓			
					Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routines
						ESM - Electronic selector module		✓	✓	✓	✓	✓	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.
						DTR - Distronic		✓	✓	✓	✓		Control unit adaptations
						ME2- SFI - Motor electronics		✓	✓	✓	✓	✓	
						ME- SFI 2.7 - Motor electronics 2.7		✓	✓	✓	✓	✓	
						CDI 3- Common Rail Diesel Injection 3		✓	✓	✓	✓		
						CDI-V - Common Rail Diesel Injection		✓	✓	✓	✓		
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking
						AIRmatic		✓	✓	✓	✓	✓	Initial startup Level calibration
						TPC - Tire pressor monitor		✓	✓	✓	✓	✓	Control unit adaptations
						ABC - ABC active body control		✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
					Body	AB - Airbag		✓	✓	✓	✓	✓	Read coding and change if necessary Chassis number
						CGW - Central gateway		✓	✓	✓			
						RevETR-LF - Left front reversible emergency tensinoing retrator		✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tensinoing retrator		✓	✓	✓	✓		
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch ELCODE(DAS 3)		✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	
						HLCM-L - Left headlamp control module		✓	✓	✓	✓	✓	
						HLCM-R - Right headlamp control module		✓	✓	✓	✓		
						UCP - Upper control panel		✓	✓	✓	✓	✓	

Mercedes	All	2004-2006	S-CLASS	220	PSE - Pneumatic system equipment		√	√	√	√	√	Lower or raise head restraints Read coding and change if necessary	
					SAM-FL - Front left signal acquisition and actuation module		√	√	√	√	√		
					SAM-FR - Front right signal acquisition and actuation module		√	√	√	√	√		
					REAR SAM - Rear signal acquisition and actuation module		√	√	√	√	√		
					System diagnosis(Only interior CAN fault)		√	√	√	√			
					AHE - Trailer recognition		√	√	√	√	√	Control unit adaptations	
					KG - Keyless Go		√	√	√	√	√		
					SVMCM - Special vehicle multifunction control module		√	√	√				
					Information and communication	ICM - Instrument cluster with maintenance interval display		√	√	√	√	√	ASSYST settings
						SCM - Steering column module		√	√	√	√	√	Initial startup
						PTS - Parktronic system		√	√	√	√	√	
						AGW/D2B - Audio gateway(MOST network management,diagnosis gateway,radio tuner)/COMAND or AUDIO		√	√	√	√	√	
						COMAND/SOUND - COMAND(Disply and operating unit)/Sound system		√	√	√	√		
						CDC - CD changer		√	√	√	√		
						HFS - Handsfree system and microphone		√	√	√		√	
						TV - TV tuner(Not valid for Japan and USA)		√	√	√	√		
						CTEL - Fixed installation cellular telephone/Cellular telephone 1		√	√	√	√		
						NAVI - Navigation ( Only in combination with COMAND ) ( Not valid for Japan)		√	√	√			
						VCS - Voice control system		√	√	√			
						TELE AID,E-call or cellular telephone - Telematic system(K-wire)		√	√	√	√	√	
						Seats and Doors	DCM-FL - Door control module front left		√	√	√	√	√
					DCM-FR - Door control module front right			√	√	√	√	√	
					DCM-RL - Door control module rear left			√	√	√	√	√	
					DCM-RR - Door control module rear right			√	√	√	√	√	
					ESA-FL - Electric seat adjustment front left			√	√	√	√	√	
					ESA-FR - Electric seat adjustment front right			√	√	√	√	√	
					ESA-R - Electric seat adjustment rear			√	√	√	√	√	
					DS-LF - Left front dynamic seat		√	√	√	√	√		

					DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
					OSB-FL - Multicontour backrest front left		✓	✓	✓	✓	✓	
					OSB-FR - Multicontour backrest front right		✓	✓	✓	✓	✓	
					OSB-R - Multiicontour backrest rear		✓	✓	✓	✓		
				Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary
					REAR AC - Rear air conditioning		✓	✓	✓	✓	✓	
					STH - Stationary heater		✓	✓	✓	✓	✓	
					HSW - Heated steering wheel		✓	✓	✓			
				Drive	Transmission( Drive train CAN bus )		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
					ISM - Intelligent servo module( Drive train CAN bus )		✓	✓	✓	✓	✓	
					ME 9.7 - Motor electronics 9.7( Chassis CAN bus )		✓	✓	✓	✓	✓	
					CDI 5 -Common Rail Diesel Injection( Chassis CAN bus )		*	*	*	*		
					DTR - Distronic( Vehicle dynamics CAN bus )		✓	✓	✓	✓		
					SGR - Rader sensors control unit( Chassis CAN bus )		✓	✓	✓	✓	✓	
				Chassis	ABR - Adaptive Brake( Chassis CAN bus )		✓	✓	✓	✓	✓	
					Electronic parking brake - Electric parking brake( Front end CAN bus )		✓	✓	✓	✓	✓	
					Suspension( Chassis CAN bus )		✓	✓	✓	✓	✓	
					ABC - ABC active body control		✓	✓	✓	✓	✓	Initial startup
					TPC - Tire pressure monitor( Interior CAN bus )		✓	✓	✓	✓	✓	
					CGW - Central gateway( Central CAN bus )		✓	✓	✓			
					EIS - Electronic ignition switch( Interior CAN bus )		✓	✓	✓	✓	✓	
					KG - Keyless Go( Interior CAN bus )		✓	✓	✓	✓	✓	
					AB - Airbag( Chassis CAN bus )		✓	✓	✓	✓	✓	
					WSS - Weight sensing system(USA)( Interior CAN bus )		✓	✓	✓			
					Dr-side SAM - Driver signal acquisition and actuation module( Interior CAN bus )		✓	✓	✓	✓	✓	
					REAR SAM - Rear signal acquisition and actuation module( Interior CAN bus )		✓	✓	✓	✓		

Mercedes	All	2007-2009	S-CLASS	221	Body	XALWA-L - Xenon headlamp,left( Front end CAN bus )		✓	✓	✓	✓	✓	
						XALWA-R - Xenon headlamp,right( Front end CAN bus )		✓	✓	✓	✓	✓	
						OCP - Overhead control panel( Interior CAN bus )		✓	✓	✓	✓	✓	
						UCP - Upper control panel( Interior CAN bus )		✓	✓	✓	✓	✓	
						RevETR-LF - Left front reversible emergency tensioning retractor( Chassis CAN bus )		✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tensioning retractor( Chassis CAN bus )		✓	✓	✓	✓		
						System diagnosis( Diagnose CAN bus )		✓	✓	✓			
						BNS - Vehicle power supply control module( Chassis CAN bus )		✓	✓	✓	✓	✓	
						IC - Instrument cluster( Central CAN bus )		✓	✓	✓	✓	✓	Setting main odometer forward and back Setting days since initial registration Resetting menu settings to manufacturer default settings
				ASSYST Active Service System( Diagnose CAN bus )		✓	✓	✓	✓	✓	AssystSetting		
				ASSYST PLUS - PLUS Active Service System( Diagnose CAN bus )		✓	✓	✓	✓	✓	General servicing Internal Assyst plus data(Reading of main odometer) Internal Assyst plus data(Days since initial registration) Average mileage per day		
				SCM - Steering column module( Chassis CAN bus )		✓	✓	✓	✓	✓			
				NSA - Night vision assist( Vehicle dynamics CAN bus )		✓	✓	✓	✓	✓			
				PTS - Parktronic system( Interior CAN bus )		✓	✓	✓	✓	✓			
				RFK - Backup column module( Interior CAN bus )		✓	✓	✓	✓				
				COMAND - COMAND with integral telematics gateway(MOST network management, diagnosis gateway)		✓	✓	✓	✓	✓			
				Tuner - Radio tuner with amplifier		✓	✓	✓					
				CTEL - Mobile telephone adapter with universal interface		✓	✓	✓	✓	✓			
				VCS - Voice control(Linguatronic)		✓	✓	✓	✓	✓			
TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓								

					SDAR - Satellite radio (Valid for USA)		✓	✓	✓	✓	✓		
					ZAN - Central Display		✓	✓	✓				
					COU[ZBE] - Central operating unit( Telematic CAN bus )		✓	✓	✓	✓	✓		
				Seats and Doors	DCM-FL - Door control module front left( Interior CAN bus )		✓	✓	✓	✓	✓	Initialization of power closing	
					DCM-FR - Door control module front right( Interior CAN bus )		✓	✓	✓	✓	✓	Initialization of power closing	
					DCM-RL - Door control module rear left( Interior CAN bus )		✓	✓	✓	✓	✓	Initialization of power closing	
					DCM-RR - Door control module rear right( Interior CAN bus )		✓	✓	✓	✓	✓	Initialization of power closing	
					ESA-FL - Electric seat adjustment front left( Interior CAN bus )		✓	✓	✓	✓	✓		
					ESA-FR - Electric seat adjustment front right( Interior CAN bus )		✓	✓	✓	✓	✓		
					ESA-R - Electric seat adjustment rear( Interior CAN bus )		✓	✓	✓	✓	✓		
					DS-LF - Left front dynamic seat( Interior CAN bus )		✓	✓	✓	✓			
					DS-RF - Right front dynamic seat( Interior CAN bus )		✓	✓	✓	✓			
					DSP - Pneumatic pump for dynamic seat( Interior CAN bus )		✓	✓	✓	✓			
					TLC - Trunk lid control( Interior CAN bus )		✓	✓	✓	✓	✓		
					Air conditioning	AAC - Automatic air conditioning( Interior CAN bus )		✓	✓	✓	✓	✓	
						KBE-H - Rear A/C operating unit( Telematic CAN bus )		✓	✓	✓			
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit	
					ESM - Electronic selector module		✓	✓	✓	✓	✓	Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.	
					DTR - Distronic		✓	✓	✓	✓		Control unit adaptations	
					ME2- SFI - Motor electronics		✓	✓	✓	✓	✓		
					ME- SFI 2.7 - Motor electronics 2.7		✓	✓	✓	✓	✓		



Mercedes	All	1999-2002	CL	215	Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking
						ABC - ABC active body control		✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
						TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Control unit adaptations
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						OCP - Overhead control panel		✓	✓	✓	✓	✓	Setting of limit position of excess force limiter Read coding and change if necessary
						EIS - Electronic ignition switch ELCODE(DAS 3)		✓	✓	✓	✓		
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						PSE - Pneumatic system equipment		✓	✓	✓	✓	✓	Lower or raise head restraints Read coding and change if necessary
						SAM-FL - Front left signal acquisition and actuation module		✓	✓	✓	✓	✓	
						SAM-FR - Front right signal acquisition and actuation module		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
						AHE - Trailer recognition		✓	✓	✓	✓	✓	Control unit adaptations
						KG - Keyless Go		✓	✓	✓	✓	✓	
						SVMCM - Special vehicle multifunction control module		✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	ASSYST settings
						SCM - Steering column module		✓	✓	✓	✓	✓	Initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓			
						SOUND - Sound system		✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		✓	✓	✓			
						TV - TV tuner		✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic system(K-wire)		✓	✓	✓	✓	✓	
						DN - Dynamic navigation by means of CTEL(K-wire)		✓	✓	✓			
						DCM-FL - Door control module front left		✓	✓	✓	✓	✓	

Seats and Doors	DCM-FR - Door control module front right		√	√	√	√	√				
	RCM - Rear control module		√	√	√	√	√				
	ESA-FL - Electric seat adjustment front left		√	√	√	√	√				
	ESA-FR - Electric seat adjustment front right		√	√	√	√	√				
	OSB-FL - Multicontour backrest front left		√	√	√	√	√				
	OSB-FR - Multicontour backrest front right		√	√	√	√	√				
Air conditioning	AAC - Automatic air conditioning		√	√	√	√	√			Initial startup Read coding and change if necessary	
	STH - Stationary heater(Up to 05/2000)		√	√	√	√	√				
	STH - Stationary heater(As of 05/2000)		√	√	√	√	√				
	HSW - Heated steering wheel		√	√	√						
Drive	Transmission		√	√	√	√	√			Initial startup Control unit adaptations Adaptations Diagnosis routiness	
	ESM - Electronic selector module		√	√	√	√	√			Detach the transport protection of control module N15/5(electronic selector lever module control module),personalizer or activate the control module.	
	DTR - Distronic		√	√	√	√				Control unit adaptations	
	ME-SFI 2.8 - Motor electronics 2.8		√	√	√	√	√				
	ME-SFI 2.7.1		√	√	√	√	√				
Chassis	ESP - Electronic stability program		√	√	√	√	√			Road test Learning processes Resetting of variant locking	
	ABC - ABC active body control		√	√	√	√	√			Calibration of the plunger travel sensors Level calibration Load adjustment	
	TPC - Tire pressure monitor		√	√	√	√	√			Control unit adaptations	
Body	AB - Airbag		√	√	√	√				Read coding and change if necessary Chassis number	
	CGW - Central gateway		√	√	√						
	OCP - Overhead control panel		√	√	√	√	√				
	EIS - Electronic ignition switch ELCODE(DAS 3)		√	√	√	√					
	HLCM-L - Left headlamp control module		√	√	√	√	√				
	HLCM-R - Right headlamp control module		√	√	√	√					
	UCP - Upper control panel		√	√	√	√	√				
	PSE - Pneumatic system equipment		√	√	√	√	√			Lower or raise head restraints Read coding and change if necessary	

Mercedes	All	2003-2006	CL	215	SAM-FL - Front left signal acquisition and actuation module		✓	✓	✓	✓	✓		
					SAM-FR - Front right signal acquisition and actuation module		✓	✓	✓	✓	✓		
					REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓		
					System diagnosis(Only interior CAN fault)		✓	✓	✓	✓			
					AHE - Trailer recognition		✓	✓	✓	✓	✓	Control unit adaptations	
					KG - Keyless Go		✓	✓	✓	✓	✓		
					SVMCM - Special vehicle multifunction control module		✓	✓	✓				
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	ASSYST settings
						SCM - Steering column module		✓	✓	✓	✓	✓	initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management, diagnosis gateway, radio tuner)		✓	✓	✓	✓	✓	
						COMAND - COMAND(Display and operating unit)		✓	✓	✓	✓		
						CDC - CD changer		✓	✓	✓	✓		
						HFS - Handsfree system and microphone		✓	✓	✓		✓	
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓		
						CTEL - Fixed installation cellular telephone		✓	✓	✓	✓		
						NAVI - Navigation ( Only in combination with COMAND ) ( Not valid for Japan )		✓	✓	✓	✓	✓	
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
						RCM - Rear control module		✓	✓	✓	✓	✓	
						ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓	
						ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓	
						OSB-FL - Multicontour backrest front left		✓	✓	✓	✓	✓	
						OSB-FR - Multicontour backrest front right		✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary
						REAR AC - Rear air conditioning		✓	✓	✓	✓	✓	
						STH - Stationary heater		✓	✓	✓	✓	✓	
						HSW - Heated steering wheel		✓	✓	✓			
						Transmission( Drive train CAN bus )		✓	✓	✓	✓	✓	

Drive	ISM - Intelligent servo module( Drive train CAN bus )	✓	✓	✓	✓	✓	
	ME 9.7 - Motor electronics 9.7( Chassis CAN bus )	✓	✓	✓	✓	✓	
	ME 2.7.2 - Motor electronics 2.7.2( Chassis CAN bus )	✓	✓	✓	✓	✓	
	FSCU - Fuel pump( Drive train CAN bus )	✓	✓	✓	✓	✓	
	DTR - Distronic( Vehicle dynamics CAN bus )	✓	✓	✓	✓		
	SGR - Rader sensors control unit( Chassis CAN bus )	✓	✓	✓	✓	✓	
Chassis	ABR - Adaptive Brake( Chassis CAN bus )	✓	✓	✓	✓		
	Electronic parking brake - Electric parking brake( Front end CAN bus )	✓	✓	✓	✓	✓	
	TPC - Tire pressure monitor( Interior CAN bus )	✓	✓	✓	✓	✓	
	Suspension( Chassis CAN bus )	✓	✓	✓	✓	✓	
Body	AB - Airbag( Chassis CAN bus )	✓	✓	✓	✓		
	WSS - Weight sensing system(USA)( Interior CAN bus )	✓	✓	✓			
	CGW - Central gateway( Central CAN bus )	✓	✓	✓			
	EZS - Electronic ignition switch( Interior CAN bus )	✓	✓	✓	✓		
	KG - Keyless Go( Interior CAN bus )	✓	✓	✓	✓	✓	
	XALWA-L - Xenon headlamp,left( Front end CAN bus )	✓	✓	✓	✓	✓	
	XALWA-R - Xenon headlamp,right( Front end CAN bus )	✓	✓	✓	✓	✓	
	OCP - Overhead control panel( Interior CAN bus )	✓	✓	✓	✓	✓	
	UCP - Upper control panel( Interior CAN bus )	✓	✓	✓	✓	✓	
	COU[ZBE] - Central operating unit( Telematic CAN bus )	✓	✓	✓	✓	✓	
	HBF(Rear control panel) - Rear control field( Telematic CAN bus )	✓	✓	✓	✓	✓	
	Dr-side SAM - Driver signal acquisition and actuation module( Interior CAN bus )	✓	✓	✓	✓	✓	
	REAR SAM - Rear signal acquisition and actuation module( Interior CAN bus )	✓	✓	✓	✓		
	System diagnosis( Diagnose CAN bus )	✓	✓	✓			
	BNS - Vehicle power supply control module( Chassis CAN bus )	✓	✓	✓	✓	✓	

Mercedes	All	2008-2009	CL	216	Information and communication	AHE - Trailer recognition( Interior CAN bus )		✓	✓	✓	✓	✓	
						NSA - Night vision assist( Vehicle dynamics CAN bus )		✓	✓	✓	✓	✓	
						IC - Instrument cluster( Central CAN bus )		✓	✓	✓	✓	✓	
						ASSYST Active Service System( Diagnose CAN bus )		✓	✓	✓	✓		
						ASSYST PLUS - PLUS Active Service System( Diagnose CAN bus )		✓	✓	✓	✓		
						SCM - Steering column module( Chassis CAN bus )		✓	✓	✓	✓	✓	
						RFK - Backup column module( Interior CAN bus )		✓	✓	✓	✓	✓	
						PTS - Parktronic system( Interior CAN bus )		✓	✓	✓	✓	✓	
						COMAND - COMAND with integral telematics gateway(MOST network management, diagnosis gateway)		✓	✓	✓	✓	✓	
						Tuner - Radio tuner with amplifier		✓	✓	✓			
						CTEL - Mobile telephone adapter with universal interface		✓	✓	✓	✓	✓	
						VCS - Voice control(Linguatronic)		✓	✓	✓	✓	✓	
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓	
						SDAR - Satellite radio (Valid for USA)		✓	✓	✓	✓	✓	
						ZAN - Central Display		✓	✓	✓			
						COU[ZBE] - Central operating unit( Telematic CAN bus )		✓	✓	✓	✓	✓	
						KBE-H -Rear A/C operating unit		✓	✓	✓	✓	✓	
					Seats and Doors	DCM-FL - Door control module front left( Interior CAN bus )		✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right( Interior CAN bus )		✓	✓	✓	✓	✓	
						ESA-FL - Electric seat adjustment front left( Interior CAN bus )		✓	✓	✓	✓	✓	
						ESA-FR - Electric seat adjustment front right( Interior CAN bus )		✓	✓	✓	✓	✓	
						DS-LF - Left front dynamic seat( Interior CAN bus )		✓	✓	✓	✓		
						DS-RF - Right front dynamic seat( Interior CAN bus )		✓	✓	✓	✓		
						DSP - Pneumatic pump for dynamic seat( Interior CAN bus )		✓	✓	✓	✓		
						TLC - Trunk lid control( Interior CAN bus )		✓	✓	✓	✓	✓	

					RCM - Rear control module( Interior CAN bus )		✓	✓	✓	✓	✓	
				Air conditioning	AAC - Automatic air conditioning( Interior CAN bus )		✓	✓	✓	✓	✓	
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
					ESM - Electronic selector module		✓	✓	✓	✓	✓	
					DTR - DISTRONIC		✓	✓	✓			
					ME-SFI 2.7.1 - Motor electronics 2.7.1		✓	✓	✓	✓	✓	
					ME-SFI 2.7.2 - Motor electronics 2.7.2		✓	✓	✓	✓	✓	
					SGR - Radar sensors control unit		✓	✓	✓	✓	✓	
				Chassis	SBCL - Sensotronic Brake Control Left		✓	✓	✓	✓		Deactive system Active system Control unit adaptations
					SBCL - Sensotronic Brake Control Right		✓	✓	✓	✓		
					ESP - Electronic stability program		✓	✓	✓	✓	✓	
					AIRmatic - AIRmatic		✓	✓	✓	✓	✓	
					TPC - Tire pressor monitor		✓	✓	✓	✓		
				Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number
					BNS - Vehicle power supply control module		✓	✓	✓			
					CGW - Central gateway		✓	✓	✓			
					EIS - Electronic ignition switch/KG - Keyless Go(Special equipment)		✓	✓	✓	✓	✓	
					HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	
					OCP - Overhead control panel		✓	✓	✓	✓	✓	
					CRN - Center roof node		✓	✓	✓			
					VBF(Front control panel) - Front control panel		✓	✓	✓	✓		
					HBF(Rear control panel) - Rear control field		✓	✓	✓	✓		
					PSE - Pneumatic system equipment		✓	✓	✓			
					Dr-side SAM - Dr. signal acquisition and actuation module		✓	✓	✓	✓	✓	
				Pass-side SAM - Pass-side signal acquisition and actuation module		✓	✓	✓	✓	✓		

Mercedes	All	2000-2009	Maybach	240	REAR SAM 1 - Rear signal acquisition and actuation module 1		√	√	√	√	√	
					REAR SAM 2 - Rear signal acquisition and actuation module 2		√	√	√	√	√	
					System diagnosis(only interior CAN fault)		√	√	√	√		
					SVMCM - Special vehicle multifunction control module		√	√	√	√	√	
					Information and communication	ICM - Instrument cluster		√	√	√	√	
						SCM[MRM] - Steering column module		√	√	√	√	initial startup
						PTS - Parktronic system		√	√	√	√	√
						AGW - Audio gateway		√	√	√	√	
						COMAND/AUDIO - Audio50 or COMAND		√	√	√	√	√
						CDC - CD changer		√	√	√	√	
						CTEL - Telephone adapter for portable CTEL		√	√	√	√	
						NAVI - Navigation (Valid for China and Korea)		√	√	√		
						VCS -Voice control		√	√	√		
						TV - TV tuner		√	√	√		
						SOUND - Bose sound system		√	√	√		
						TELE - TELE AID		√	√	√		
						Seats and Doors	DCM-FL - Door control module front left		√	√	√	√
					DCM-FR - Door control module front right			√	√	√	√	√
					DCM-RL - Door control module rear left			√	√	√	√	√
					DCM-RR - Door control module rear right			√	√	√	√	√
					PWC - Partition wall control module			√	√	√		
					LDCA - Electric left door closing assist			√	√	√		
					RDCA - Electric right door closing assist			√	√	√		
					ESA-FL - Electric seat adjustment front left			√	√	√	√	√
					ESA-FR - Electric seat adjustment front right			√	√	√	√	√
					ESA-LR - Left rear electrical seat adjustment			√	√	√		
					ESA-RR - Right rear electrical seat adjustment			√	√	√		
					OSB-FL - Multicontour backrest front left			√	√	√		
					OSB-FR - Multicontour backrest front right			√	√	√		
					MKL-HL - Rear left multicontour backrest			√	√	√		
MKL-HR - Rear right multicontour backrest		√	√	√								

						TLC - Trunk lid control		✓	✓	✓	✓	✓	
					Air conditioning	C-AAC - Convenience automatic air conditioning/AAC		✓	✓	✓	✓	✓	
						REAR AC - Rear air conditioning		✓	✓	✓			
						STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
						HSW - Heated steering wheel		✓	✓	✓			
Mercedes	All	1984-1988	SL	107	Body	AB		✓	✓	✓	✓		
Mercedes	All	1989-1998	SL	129	Drive	HFM		✓	✓	✓	✓		
						ME1RE		✓	✓	✓	✓		
						ME1LI		✓	✓	✓	✓		
						LH1		✓	✓	✓	✓		
						LH2		✓	✓	✓	✓		
						DM		✓	✓	✓	✓		
						EFP		✓	✓	✓	✓		
						TPM		✓	✓	✓	✓		
						ISC		✓	✓	✓	✓		
						GM		✓	✓	✓	✓		
					Chassis	ABS		✓	✓	✓	✓		
						ASR		✓	✓	✓	✓		
						ETS		✓	✓	✓	✓		
						ESP		✓	✓	✓	✓		
						BAS		✓	✓	✓	✓		
						ADS		✓	✓	✓	✓		
						EGS		✓	✓	✓	✓	✓	
						EAG		✓	✓	✓	✓	✓	
					Body	RFL		✓	✓	✓	✓		
						RCL(DAS2/X)		✓	✓	✓	✓		
						ATA		✓	✓	✓	✓		
						AB		✓	✓	✓	✓		
						KI		✓	✓	✓	✓	✓	
LWR		✓	✓	✓		✓	✓						
APS		✓	✓	✓		✓							
Audio,COMMAND		✓	✓	✓		✓							
TELE-AID		✓	✓	✓		✓							



						CDC		✓	✓	✓	✓			
						E-Call		✓	✓	✓	✓			
					Air conditioning	Air Conditioning		✓	✓	✓				
						STH		✓	✓	✓				
Mercedes	All	1999-2002	SL	129	Drive	ME2-SFI		✓	✓	✓	✓	✓		
						ME1RE		✓	✓	✓	✓			
						ME1LI		✓	✓	✓	✓			
						ETC		✓	✓	✓	✓	✓		
					Chassis	ABS,ASR,ETS,ESP		✓	✓	✓	✓	✓		Control unit adaptations
						BAS		✓	✓	✓	✓			
						ADS		✓	✓	✓	✓			
					Body	AB		✓	✓	✓	✓		Control unit adaptations	
						HRA		✓	✓	✓	✓			
						ATA		✓	✓	✓	✓	✓		
						RFL		✓	✓	✓	✓	✓		
						RS		✓	✓	✓	✓	✓		
					Information and communication	ICM		✓	✓	✓	✓	✓	Setting	
						TELE AID,E-call		✓	✓	✓	✓	✓		
						DN		✓	✓	✓				
						D2B		✓	✓	✓	✓	✓	Read coding and change if necessary	
						CDC		✓	✓	✓				
						VCS		✓	✓	✓				
						CTEL		✓	✓	✓				
					Air conditioning	APS		✓	✓	✓				
STH		✓	✓	✓		✓								
					AAC		✓	✓	✓	✓		Read coding and change if necessary		
					Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit	
						ESM - Electronic selector module		✓	✓	✓	✓	✓		
						DTR - Distronic		✓	✓	✓	✓	✓	Control unit adaptations	
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓		

Mercedes	All	Up to 08/20 03	SL	230	Chassis	SBC - Sensotronic Brake Control		✓	✓	✓	✓		Deactive system Active system Control unit adaptations
						ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test Erase zero point offset error of component N49(steering angle sensor)
						ABC - ABC active body control		✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
						TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Control unit adaptations
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						BNS - Vehicle power supply control module		✓	✓	✓	✓		
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch		✓	✓	✓	✓		
						HRA-FL - Front left headlamp range control		✓	✓	✓	✓	✓	
						HRA-FR - Front right headlamp range control		✓	✓	✓	✓		
						LCP - Lower control panel		✓	✓	✓	✓	✓	
						PSE - Pneumatic system equipment		✓	✓	✓	✓	✓	Read coding and change if necessary
						Dr-side SAM - Dr. signal acquisition and actuation module		✓	✓	✓	✓	✓	
						Pass-side SAM - Pass-side signal acquisition and actuation module		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
						RVC - Rollover bar/vario roof control module		✓	✓	✓	✓	✓	
						KG - Keyless Go		✓	✓	✓	✓	✓	
						System diagnosis		✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	ASSYST settings
						SCM - Steering column module		✓	✓	✓	✓	✓	initial startup
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓			
						SOUND - Sound system		✓	✓	✓			
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		✓	✓	✓			

					TELE AID,E-call or cellular telephone - Telematic system(K-wire)		✓	✓	✓	✓		
					TV - TV tuner(Not valid for Japan)		✓	✓	✓		✓	
				Seats and Doors	DCM-L - Door control module left		✓	✓	✓	✓	✓	
					DCM-R - Door control module right		✓	✓	✓	✓	✓	
					RCM - Rear control module		✓	✓	✓	✓	✓	
					ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓	
					ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓	
					OSB-FL - Multicontour backrest front left		✓	✓	✓	✓	✓	
					OSB-FR - Multicontour backrest front right		✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓
				STH - Stationary heater with remote control			✓	✓	✓	✓	✓	
				HSW - Heated steering wheel			✓	✓	✓			
				Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
					ESM - Electronic selector module		✓	✓	✓	✓	✓	
					DTR - Distronic		✓	✓	✓	✓	✓	Control unit adaptations
					ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
					ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓	
					ME-SFI 2.7.1 - Motor electronics 2.7.1		✓	✓	✓	✓	✓	
				Chassis	SBC - Sensotronic Brake Control		✓	✓	✓	✓		Deactive system Active system Control unit adaptations
					ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test Erase zero point offset error of component N49(steering angle sensor)
					ABC - ABC active body control		✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
					TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Control unit adaptations
					AB - Airbag		✓	✓	✓	✓	✓	Read coding and change if necessary Chassis number
					WSS - Weight sensor system(USA)		✓	✓	✓			

Mercedes	All	09/20 03- 05/20 06	SL	230	Body	CGW - Central gateway		√	√	√			
						BNS - Vehicle power supply control module		√	√	√	√		
						OCP - Overhead control panel		√	√	√	√	√	
						EIS - Electronic ignition switch		√	√	√	√		
						HRA-FL - Front left headlamp range control		√	√	√	√	√	
						HRA-FR - Front right headlamp range control		√	√	√	√		
						LCP - Lower control panel		√	√	√	√	√	
						PSE - Pneumatic system equipment		√	√	√	√	√	Read coding and change if necessary
						Dr-side SAM - Dr. signal acquisition and actuation module		√	√	√	√	√	
						Pass-side SAM - Pass-side signal acquisition and actuation module		√	√	√	√	√	
						REAR SAM - Rear signal acquisition and actuation module		√	√	√	√	√	
						RVC - Rollover bar/vario roof control module		√	√	√	√	√	
						KG - Keyless Go		√	√	√	√	√	
						System diagnosis		√	√	√	√		
						Information and communication	ICM - Instrument cluster with maintenance interval display		√	√	√	√	
					SCM - Steering column module			√	√	√	√	√	initial startup
					PTS - Parktronic system			√	√	√	√	√	
					AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)			√	√	√	√		
					COMAND - COMAND(Displaly and operating unit)			√	√	√	√	√	
					CDC - CD changer			√	√	√	√		
					HFS - Handsfree system and microphone			√	√	√	√		
					TV - TV tuner(Not valid for Japan and USA)			√	√	√	√		
					CTEL - Fixed installation cellular telephone			√	√	√	√		
					MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal			√	√	√			
					VCS - Voice control system			√	√	√			
					TELE AID,E-call or cellular telephone - Telematic system(K-wire)			√	√	√	√		
					Seats and	DCM-L - Door control module left		√	√	√	√	√	
						DCM-R - Door control module right		√	√	√	√	√	
						RCM - Rear control module		√	√	√	√	√	

					Seats and Doors	ESA-FL - Electric seat adjustment front left	✓	✓	✓	✓	✓	
						ESA-FR - Electric seat adjustment front right	✓	✓	✓	✓	✓	
						OSB-FL - Multicontour backrest front left	✓	✓	✓	✓	✓	
						OSB-FR - Multicontour backrest front right	✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
						STH - Stationary heater with remote control	✓	✓	✓	✓	✓	
						HSW - Heated steering wheel	✓	✓	✓			
					Drive	Transmission	✓	✓	✓	✓	✓	
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						DTR - Distronic	✓	✓	✓	✓	✓	Control unit adaptations
						ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
						ME 9.7 - Motor electronics 9.7	✓	✓	✓	✓	✓	
						ME-SFI 2.7.1 - Motor electronics 2.7.1	✓	✓	✓	✓	✓	
						ME-SFI 2.7.2 - Motor electronics 2.7.2	✓	✓	✓	✓	✓	
					Chassis	SBC - Sensotronic Brake Control	✓	✓	✓	✓	✓	
						ESP - Electronic stability program	✓	✓	✓	✓	✓	Replacement of component B24/15 Road test
						ABC - ABC active body control	✓	✓	✓	✓	✓	Calibration of the plunger travel sensors Level calibration Load adjustment
						TPC - Tire pressure monitor	✓	✓	✓	✓	✓	Control unit adaptations
					Body	AB - Airbag	✓	✓	✓	✓		Display coded vehicle data
						WSS - Weight sensor system(USA)	✓	✓	✓			
						CGW - Central gateway	✓	✓	✓			
						BNS - Vehicle power supply control module	✓	✓	✓	✓		
						OCP - Overhead control panel	✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch	✓	✓	✓	✓		
						HRA-FL - Front left headlamp range control	✓	✓	✓	✓	✓	
						HRA-FR - Front right headlamp range control	✓	✓	✓	✓	✓	
						LCP - Lower control panel	✓	✓	✓	✓	✓	
						PSE - Pneumatic system equipment	✓	✓	✓	✓	✓	

Mercedes	All	06/20 06- 02/20 08	SL	230	Dr-side SAM - Dr. signal acquisition and actuation module	√	√	√	√	√		
					Pass-side SAM - Pass-side signal acquisition and actuation module	√	√	√	√	√		
					REAR SAM - Rear signal acquisition and actuation module	√	√	√	√	√	Flashing stop lamp/Rear foglight	
					RVC - Rollover bar/vario roof control module	√	√	√	√	√		
					KG - Keyless Go	√	√	√	√	√		
					System diagnosis	*	*	*	*			
					Information and communication	ICM - Instrument cluster with maintenance interval display	√	√	√	√		
						SCM - Steering column module	√	√	√	√	√	
						PTS - Parktronic system	√	√	√	√	√	
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)	*	*	*	*	*	1.Specified configuration of MOST components 2.Apply actual configuration of the MOST components as the specified configuration 3.Restart of optical ring
						COMAND - COMAND(Display and operating unit)	*	*	*	*	*	1.Radio parameters 2.TV parameters(Shut off criteria) 3.Restart of optical ring
						CDC - CD changer	*	*	*	*		
						HFS - Handsfree system and microphone	√	√	√	√		
						TV - TV tuner(Not valid for Japan and USA)	√	√	√	√		
						CTEL - Fixed installation cellular telephone	*	*	*	*		
						MB Portal - Telematic services WAP,E-mail,Mercedes-Benz Portal	√	√	√			
						VCS - Voice control system	√	√	√			
						TELE AID,E-call or cellular telephone - Telematic system(K-wire)	√	√	√	√		
						NAVI - Navigation(Only in combination with COMAND)(Not valid for Japan)	*	*	*	*		
						Seats and Doors	DCM-L - Door control module left	√	√	√	√	√
					DCM-R - Door control module right		√	√	√	√	√	
					RCM - Rear control module		√	√	√	√	√	
					ESA-FL - Electric seat adjustment front left		√	√	√	√	√	
					ESA-FR - Electric seat adjustment front right		√	√	√	√	√	
					OSB-FL - Multicontour backrest front left		√	√	√	√	√	
					OSB-FR - Multicontour backrest front right		√	√	√	√	√	

					Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓		
						STH - Stationary heater with remote control		✓	✓	✓	✓	✓		
						HSW - Heated steering wheel		✓	✓	✓				
Mercedes	All	2002-2009	SLR	199	Drive	Transmission		✓	✓	✓	✓	✓		Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module		✓	✓	✓	✓	✓		
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓		
					Chassis	SBC - Sensotronic Brake Control		✓	✓	✓	✓		Deactive system Active system Control unit adaptations	
						ESP - Electronic stability program		✓	✓	✓	✓			
						TPC - Tire pressure monitor		✓	✓	✓	✓	✓	Read coding and change if necessary	
					Body	AB - Airbag		✓	✓	✓	✓			
						CGW - Central gateway		✓	✓	✓				
						BNS - Vehicle power supply control module		✓	✓	✓	✓			
						OCP - Overhead control panel		✓	✓	✓	✓	✓		
						EIS - Electronic ignition switch		✓	✓	✓	✓			
						HRA-FR - Front right headlamp range control		✓	✓	✓	✓	✓		
						HRA-FL - Front left headlamp range control		✓	✓	✓	✓	✓		
						LCP - Lower control panel		✓	✓	✓	✓	✓		
						Dr-side SAM - Driver signal acquisition and actuation moduel		✓	✓	✓	✓	✓		
						Pass-side SAM - Passenger-side signal acquisition and actuation module		✓	✓	✓	✓	✓		
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓		
					ACL[ZLB] - Air brake(spoiler)and central locking control unit		✓	✓	✓					
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓		
						SCM - Steering column module		✓	✓	✓	✓	✓	initial startup	
D2B - AUDIO		✓	✓	✓		✓	✓							
CDC - CD changer		✓	✓	✓										
SOUND - Sound system		✓	✓	✓		✓								

						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		✓	✓	✓			
						TELE AID - Telematic system(K-wrie)		✓	✓	✓	✓		
					Seats and Doors	DCM-L - Door control module left		✓	✓	✓	✓	✓	
						DCM-R - Door control module right		✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning		✓	✓	✓	✓	✓	
Mercedes	All	1996-1998	SLK	170(38-PIN)	Drive	ETC - Electronic transmission control		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						HFM-SFI - Hot film engine management		✓	✓	✓	✓		
						ME2-SFI - Motor electronics		✓	✓	✓	✓		
					Chassis	Traction systems ABS,ASR,ETS,ESP		✓	✓	✓	✓	✓	Road test Learning processes Resetting of variant locking
						BAS - Brake assist		✓	✓	✓	✓	✓	
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Coded vehicle data
						RFL - Radio frequency locking/electric central locking		✓	✓	✓	✓	✓	
						RFL(DAS2) - Radio frequency locking(drive authorization stage 2)		✓	✓	✓	✓	✓	
						PSE - Pneumatic system equipment		✓	✓	✓	✓	✓	
						CCM - Multifunction control module		✓	✓	✓	✓	✓	
						VR - Vario roof		✓	✓	✓	✓	✓	
						ATA - Anti-theft alarm system		✓	✓	✓	✓	✓	
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	
						D2B - AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓			
					Air conditioning	CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		✓	✓	✓			
						TAC - Automatic temperature control/AAC - Automatic air conditioning		✓	✓	✓	✓	✓	



Mercedes	All	1999-2004	SLK	170(16-PIN)	Drive	Transmission		√	√	√	√	√	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module		√	√	√	√	√	
						ME-SFI - Motor electronics		√	√	√	√	√	
					Chassis	ESP - Electronic stability program		√	√	√	√	√	
						BAS - Brake assist		√	√	√	√	√	
						VP - Vacuum pump brake booster		√	√	√	√	√	
					Body	AB - Airbag		√	√	√	√		Read coding and change if necessary Coded vehicle data
						RFL - Radio frequency locking/electric central locking		√	√	√	√	√	
						PSE - Pneumatic system equipment		√	√	√	√	√	
						CCM - Multifunction control module		√	√	√	√	√	
						VR - Vario roof		√	√	√	√	√	
						ATA - Anti-theft alarm system		√	√	√	√	√	
						HRA - Headlamp range adjustment		√	√	√	√	√	
					Information and communication	ICM - Instrument cluster with maintenance interval display		√	√	√	√	√	
						D2B - AUDIO		√	√	√	√	√	Read coding and change if necessary
						CDC - CD changer		√	√	√			
						VCS - Voice control, hands-free system and microphones		√	√	√			
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		√	√	√			
						TELE AID, E-call or cellular telephone - Telematic system(K-wrie)		√	√	√			
					Air conditioning	TAC - Automatic temperature control/AAC - Automatic air conditioning		√	√	√	√	√	
						STH - Stationary heater		√	√	√			
					Drive	Transmission		√	√	√	√	√	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ESM - Electronic selector module		√	√	√	√	√	
ME-SFI - Motor electronics		√	√	√		√	√						

Mercedes	All	2005	SLK	171	ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓			
					ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓			
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓		Road test
					Body	AB - Airbag		✓	✓	✓	✓			Read coding and change if necessary Chassis number
						CGW - Central gateway		✓	✓	✓				
						EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)		✓	✓	✓	✓			
						VR - Vario roof		✓	✓	✓	✓	✓		
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors	
						OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panoramic sliding roof	
						UCP - Upper control panel		✓	✓	✓	✓	✓		
						SAM-F - Signal acquisition and actuation module front		✓	✓	✓	✓	✓		
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓		
						On-board electrical system(voltage supply)		✓	✓	✓	✓			
						System diagnosis		✓	✓	✓	✓			
					Information and communication	IC - Instrument cluster		✓	✓	✓	✓	✓		
						ASSYST Active Service System		✓	✓	✓	✓		AssystSetting	
						ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations	
						SCM[MRM] - Steering column module		✓	✓	✓	✓	✓	initial startup	
						PTS - Parktronic system		✓	✓	✓	✓	✓		
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)		✓	✓	✓	✓	✓		
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary	
						CDC - CD changer		✓	✓	✓	✓			
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓		
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓			
					Seats and Doors	DCM-L - Door control module left		✓	✓	✓	✓	✓	Read coding and change if necessary	
						DCM-R - Door control module right		✓	✓	✓	✓	✓	Read coding and change if necessary	
						ESA driver - Electric seat adjustment driver(with memory)		✓	✓	✓	✓	✓		

Mercedes	All	2006-2009	SLK	171	Body	ESA passenger-Electric seat adjustment FR. Pass.(with memory)		✓	✓	✓	✓	✓	
						HS - Seat heater		✓	✓	✓	✓	✓	
					Air conditioning	C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning/HEAT - Automatic heater		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors
						HSW - Heated steering wheel		✓	✓	✓	✓	✓	
					Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						ME-SFI - Motor electronics		✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
						ME 9.7 - Motor electronics 9.7		✓	✓	✓	✓	✓	
					Chassis	ESP - Electronic stability program		✓	✓	✓	✓	✓	Road test
					Body	AB - Airbag		✓	✓	✓	✓		Read coding and change if necessary Chassis number
						WSS - Weight sensor system (USA)		✓	✓	✓			
						CGW - Central gateway		✓	✓	✓			
						EIS - Electronic ignition switch/KG - Keyless GO(Special equipment)		✓	✓	✓	✓		
						VR - Vario roof		✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	Initial startup Read coding and change if necessary Zero position adjustment of axle or level sensors
						OCP - Overhead control panel		✓	✓	✓	✓	✓	Read coding and change if necessary Panornamic sliding roof
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						SAM-F - Signal acquisition and actuation module front		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
Electrical	On-board electrical system(voltage supply)		✓	✓	✓	✓							
	System diagnosis		✓	✓	✓	✓							
	IC - Instrument cluster		✓	✓	✓	✓	✓						
	ASSYST Active Service System		✓	✓	✓	✓		AssystSetting					
	ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations					

					Information and communication	SCM[MRRM] - Steering column module		✓	✓	✓	✓	✓		
						PTS - Parktronic system		✓	✓	✓	✓	✓		
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)		✓	✓	✓	✓	✓		
						COMAND/AUDIO - Audio50 or COMAND		✓	✓	✓	✓	✓	Read coding and change if necessary	
						CDC - CD changer		✓	✓	✓	✓			
						TV - TV tuner(Not valid for Japan and USA)		✓	✓	✓	✓	✓		
						CTEL - Telephone adapter for portable CTEL		✓	✓	✓	✓			
					Seats and Doors	DCM-L - Door control module left		✓	✓	✓	✓	✓		
						DCM-R - Door control module right		✓	✓	✓	✓	✓		
						ESA driver - Electric seat adjustment driver(with memory)		✓	✓	✓	✓	✓		
						ESA passenger-Electric seat adjustment FR. Pass.(with memory)		✓	✓	✓	✓	✓		
						HS - Seat heater		✓	✓	✓	✓	✓		
					Air conditioning	C-AAC - Convenience automatic air conditioning/AAC - Automatic air conditioning/HEAT - Automatic heater		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors	
						HSW - Heated steering wheel		✓	✓	✓	✓	✓		
					Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit	
						ESM - Electronic selector module		✓	✓	✓	✓	✓		
						ME2-SFI - Motor electronics 2		✓	✓	✓	✓	✓		
						CDI - Common Rail Diesel Injection		✓	✓	✓	✓			
						CDI-V1 - Common Rail Diesel Injection		✓	✓	✓	✓			
VG - Transfer case		✓	✓	✓		✓								
Chassis	Traction system ABS,ASR,ETS,ESP		✓	✓		✓	✓	✓						
	BAS - Brake assist		✓	✓		✓	✓	✓						
	AB - Airbag		✓	✓		✓	✓		Read coding and change if necessary Coded vehicle data					
	AAM - All Activity Module		✓	✓		✓	✓	✓						
	EAM - Extended activity module(As of module year 2000)		✓	✓	✓	✓	✓							

Mercedes	All	1998-2005	M-CLASS	163	Body	DAS - Drive authorization system(As of module year 2000)		✓	✓	✓	✓		
						LCP - Lower perating panel with power window function(As of module year 2002)		✓	✓	✓	✓	✓	initial startup
						SEM - Security Module(Up to module year 1999)		✓	✓	✓			
						HRA - Headlamp range adjustment(As of module year 2000)		✓	✓	✓	✓	✓	
					Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	
						PTS - Parktronic system		✓	✓	✓	✓	✓	Read coding and change if necessary
						D2B - COMAIND,MCS or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						MCS navigation in MCS		✓	✓	✓			
						MCS CD - CD player in MCS		✓	✓	✓			
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓			
						SOUND - Sound system		✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic system(K-wire)		✓	✓	✓	✓		
					Seats and Doors	ESA-FL - Electric seat adjustment front left		✓	✓	✓	✓	✓	
						ESA-FR - Electric seat adjustment front right		✓	✓	✓	✓	✓	
					Air conditioning	AAC - Automatic air conditioning(As of model year 2002)		✓	✓	✓	✓	✓	
						STH - Stationary heater		✓	✓	✓	✓		
					Drive	Transmission		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Adaptations Diagnosis routiness
						VG - Transfer case		✓	✓	✓	✓	✓	
						ISM - Intelligent servo module		✓	✓	✓	✓		
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
						ME9.7-Motor electronics 9.7		✓	✓	✓	✓	✓	
						ME 9.7(AMG) - Motor electronics 9.7(AMG)		✓	✓	✓	✓	✓	
						CDI 4 - Common Rail Diesel Injection		✓	✓	✓	✓	✓	
						CDI 5 - Common Rail Diesel Injection		✓	✓	✓	✓	✓	
					Chassis	AIRmatic		✓	✓	✓	✓	✓	
ESP - Electronic stability program		✓	✓	✓		✓	✓						

Mercedes	All	2006-2009	M-CLASS	164	Body	TPC - Tire pressure monitor		✓	✓	✓	✓		
						AB-Airbag		✓	✓	✓	✓		
						WSS - Weight sensor system (USA)		✓	✓	✓	✓		
						RevETR-LF - Left front reversible emergency tensioning retractor		✓	✓	✓	✓	✓	
						RevETR-RF - Right front reversible emergency tensioning retractor		✓	✓	✓	✓	✓	
						EIS - Electronic ignition switch/KG - Keyless Go(Special equipment)		✓	✓	✓	✓		
						CGW - Central gateway		✓	✓	✓			
						KG - Keyless Go		✓	✓	✓	✓	✓	
						HRA - Headlamp range adjustment		✓	✓	✓	✓	✓	
						OCP - Overhead control panel		✓	✓	✓	✓	✓	
						UCP - Upper control panel		✓	✓	✓	✓	✓	
						HBF(Rear control panel) - Rear control field		✓	✓	✓	✓	✓	
						SAM-F - Signal acquisition and actuation module front		✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module		✓	✓	✓	✓	✓	
						System diagnosis(only interior CAN fault)		✓	✓	✓	✓		
					Information and communication	IC - Instrument cluster		✓	✓	✓	✓	✓	
						ASSYST - Active Service System		✓	✓	✓	✓		AssystSetting
						ASSYST PLUS - PLUS Active Service System		✓	✓	✓	✓		General servicing Control unit adaptations
						CM - Compass module		✓	✓	✓	✓		
						SCM - Steering column module		✓	✓	✓	✓	✓	
						PTS - Parktronic system		✓	✓	✓	✓	✓	
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)		✓	✓	✓	✓	✓	
						COMAND /AUDIO - Audio 50(Display and operating unit with navigation) or COMAND(Display and operating unit with navigation)		✓	✓	✓	✓	✓	
						NAVI - Navigation(Only in combination with COMAND)(Valid for USA)		✓	✓	✓	✓		
						CDC - CD changer		✓	✓	✓	✓		
						SOUND - Sound system		✓	✓	✓	✓		
						CTEL - Mobile phone adapter with universal interface		✓	✓	✓	✓		



Mercedes	All	2006-2009	R-CLASS	251	OCP - Overhead control panel	✓	✓	✓	✓	✓		
					UCP - Upper control panel	✓	✓	✓	✓	✓		
					HBF(Rear control panel) - Rear control field	✓	✓	✓	✓	✓		
					SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓		
					REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓		
					System diagnosis (only interior CAN fault)	✓	✓	✓	✓			
					Information and communication	IC - Instrument cluster	✓	✓	✓	✓	✓	
						ASSYST - Active Service System	✓	✓	✓	✓		AssystSetting
						ASSYST PLUS - PLUS Active Service System	✓	✓	✓	✓		General servicing Control unit adaptations
						CM - Compass module	✓	✓	✓	✓		
						SCM - Steering column module	✓	✓	✓	✓	✓	
						PTS - Parktronic system	✓	✓	✓	✓		
						AGW - Audio 20 with integrated gateway(display and operating unit,MOST network management,diagnosis gateway,radio tuner)	✓	✓	✓	✓		
						CDC - CD changer	✓	✓	✓	✓		
						SOUND - Sound system	✓	✓	✓	✓		
						CTEL - Telephone adapter for portable CTEL	✓	✓	✓	✓		
						Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓
					DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
					REDC - Rear-end door closing control module		✓	✓	✓	✓	✓	
					ESA driver - Electric seat adjustment driver(with memory)		✓	✓	✓	✓	✓	
					ESA passenger-Electric seat adjustment FR. Pass.(with memory)		✓	✓	✓	✓	✓	
					DS-LF - Left front dynamic seat		✓	✓	✓	✓	✓	
					DS-RF - Right front dynamic seat		✓	✓	✓	✓	✓	
					DSP - Pneumatic pump for dynamic seat		✓	✓	✓	✓	✓	
					Air conditioning	HS - Seat heater	✓	✓	✓	✓	✓	
						AAC - Automatic air conditioning	✓	✓	✓	✓	✓	
						STH - Stationary heater with remote control	✓	✓	✓	✓	✓	
						HSW - Heated steering wheel	✓	✓	✓	✓	✓	
						ABS	✓	✓	✓	✓		



Mercedes	All	1991-2001	G-CLASS	461(38Pin)	ASR	✓	✓	✓	✓			
					ETS	✓	✓	✓	✓			
					ESP	✓	✓	✓	✓			
					RFL(DAS2)	✓	✓	✓	✓			
					AB	✓	✓	✓	✓			
					KI	✓	✓	✓	✓	✓		
					STH	✓	✓	✓				
Mercedes	All	2002-2007	G-CLASS	461(16Pin)	Drive	ETC - Electronic transmission control	✓	✓	✓	✓	✓	
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						VG - Transfer case	✓	✓	✓	✓		
						CDI 2 - Common Rail Diesel Injection	✓	✓	✓	✓		
					Body	AB - Airbag	✓	✓	✓	✓	✓	
						Information and communication	IC - Instrument cluster	✓	✓	✓	✓	✓
					AUDIO		✓	✓	✓	✓	✓	
Air conditioning	Air conditioning	✓	✓	✓	✓	✓						
	STH - Stationary heater	✓	✓	✓	✓							
Mercedes	All	1991-1997	G-CLASS	463(4Pin)	Drive	HFM	✓	✓	✓	✓		
						EFP	✓	✓	✓	✓		
						TPM	✓	✓	✓	✓		
						ISC	✓	✓	✓	✓		
					Body	RCL(DAS1/X)	✓	✓	✓	✓		
						RCL(DAS2/X)	✓	✓	✓	✓		
						ATA(Anti-Theft Alarm)	✓	✓	✓	✓		
AB(Air Bag)	✓	✓	✓	✓								
					Drive	ETC - Electronic transmission control	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						HFM-SFI- Hot film engine management	✓	✓	✓	✓		
						ME2-SFI - Motor electronics	✓	✓	✓	✓		
					Chassis	Traction systems ABS,ASR,ETS,ESP	✓	✓	✓	✓	✓	
						AB - Airbag	✓	✓	✓	✓	✓	Control unit adaptations

Mercedes	All	1997-	G-CLASS	463(38Pin)	Body	RFL(DAS2) - Radio frequency locking(drive authorization stage 2)	✓	✓	✓	✓	✓	
						ATA - Anti-theft alarm system	✓	✓	✓	✓	✓	
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	Clock Reset odometer to 0 km Oil change
						D2B - AUDIO	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer	✓	✓	✓			
						VCS - Voice control system	✓	✓	✓			
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	✓	✓	✓			
						APS - Auto pilot system	✓	✓	✓			
					Air conditioning	Air conditioning	✓	✓	✓	✓		Read coding and change if necessary
						STH - Stationary heater	✓	✓	✓			
					Drive	ETC - Electronic transmission control	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routines Read coding and/or transfer download to new control unit
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8	✓	✓	✓	✓	✓	
						CDI-V1 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
						CDI 2 - Common Rail Diesel Injection	✓	✓	✓	✓	✓	
						VG - Transfer case	✓	✓	✓	✓	✓	
					Chassis	Traction systems ABS,ASR,ETS,ESP	✓	✓	✓	✓	✓	
					Body	AB - Airbag	✓	✓	✓	✓		
						EIS - Electronic ignition switch	✓	✓	✓	✓		
						UCP - Upper control panel	✓	✓	✓	✓	✓	
SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓		✓						
REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓		✓						
AHE - Trailer recognition	✓	✓	✓	✓		✓						
OCP - Overhead control panel	✓	✓	✓	✓		✓						
VR - Electrohydraulic soft top	✓	✓	✓	✓		✓						
MSS - Special vehicle multifunction control module	✓	✓	✓									

Mercedes	All	-2004	G-CLASS	463(16Pin)	Information and communication	ICM - Instrument cluster with maintenance interval display		✓	✓	✓	✓	✓	
						SCM[MRRM] - Steering column module(As of model year 2002)		✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO		✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer		✓	✓	✓			
						VCS - Voice control system		✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic system(K-write)		✓	✓	✓	✓		
						TV - TV tuner		✓	✓	✓			
					Seats and Doors	DCM-FL - Door control module front left		✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right		✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left		✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right		✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment driver(with memory)		✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment front passenger(with memory)		✓	✓	✓	✓	✓	
					Air conditioning	AAC- Automatic air conditioning		✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
						STH - Stationary heater with remote control		✓	✓	✓	✓	✓	
						HSW - Heated steering wheel		✓	✓	✓			
					Drive	ETC - Electronic transmission control		✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module		✓	✓	✓	✓	✓	
						ME-SFI 2.8 - Motor electronics 2.8		✓	✓	✓	✓	✓	
						CDI-V1 - Common Rail Diesel Injection		✓	✓	✓	✓	✓	
						CDI 2 - Common Rail Diesel Injection		✓	✓	✓	✓	✓	
						VG - Transfer case		✓	✓	✓	✓	✓	

Mercedes	6	2004-2006	G-CLASS	463(16Pin)	Chassis	Traction systems ABS,ASR,ETS,ESP	✓	✓	✓	✓	✓	
					Body	AB - Airbag	✓	✓	✓	✓		
						EIS - Electronic ignition switch	✓	✓	✓	✓		
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						SAM-F - Signal acquisition and actuation module front	✓	✓	✓	✓	✓	
						REAR SAM - Rear signal acquisition and actuation module	✓	✓	✓	✓	✓	
						AHE - Trailer recognition	✓	✓	✓	✓	✓	
						OCP - Overhead control panel	✓	✓	✓	✓	✓	
						VR - Electrohydraulic soft top	✓	✓	✓	✓	✓	
						MSS - Special vehicle multifunction control module	✓	✓	✓			
					Information and communication	ICM - Instrument cluster with maintenance interval display	✓	✓	✓	✓	✓	
						SCM[MRM] - Steering column module(As of model year 2002)	✓	✓	✓	✓	✓	
						D2B - COMAND or AUDIO	✓	✓	✓	✓	✓	Read coding and change if necessary
						CDC - CD changer	✓	✓	✓			
						VCS - Voice control system	✓	✓	✓	✓		
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)	✓	✓	✓			
						TELE AID,E-call or cellular telephone - Telematic system(K-write)	✓	✓	✓	✓		
						TV - TV tuner	✓	✓	✓			
					Seats and Doors	DCM-FL - Door control module front left	✓	✓	✓	✓	✓	
						DCM-FR - Door control module front right	✓	✓	✓	✓	✓	
						DCM-RL - Door control module rear left	✓	✓	✓	✓	✓	
						DCM-RR - Door control module rear right	✓	✓	✓	✓	✓	
						ESA driver - Electric seat adjustment driver(with memory)	✓	✓	✓	✓	✓	
						ESA passenger - Electric seat adjustment front passenger(with memory)	✓	✓	✓	✓	✓	
					Air conditioning	AAC- Automatic air conditioning	✓	✓	✓	✓	✓	Read coding and change if necessary Normalizing of position motors Check of adjustment range of positioning motors Teaching-in of rotary potentiometer for center nozzle and side outlets
						STH - Stationary heater with remote control	✓	✓	✓	✓	✓	

Mercedes	All	2006-2007	G-CLASS	463(16Pin)	HSW - Heated steering wheel		√	√	√					
					Drive	ETC - Electronic transmission control		√	√	√	√	√		Initial startup Control unit adaptations Adaptations Diagnosis routiness
						ESM - Electronic selector module		√	√	√	√	√		
						ME-SFI 2.8 - Motor electronics 2.8		√	√	√	√	√		
						CDI 4 - Common Rail Diesel Injection		√	√	√	√	√		
						VG - Transfer case		√	√	√	√	√		
					Chassis	ESP - Electronic stability program		√	√	√	√	√		Road test
						TPC - Tire pressure monitor		√	√	√	√	√		Read coding and change if necessary
					Body	AB - Airbag		√	√	√	√			
						EIS - Electronic ignition switch		√	√	√	√	√		
						UCP - Upper control panel		√	√	√	√	√		
						SAM-F - Signal acquisition and actuation module front		√	√	√	√	√		
						REAR SAM - Rear signal acquisition and actuation module		√	√	√	√	√		
						AHE - Trailer recognition		√	√	√	√	√		
						OCP - Overhead control panel		√	√	√	√	√		Read coding and change if necessary
						ALWR - Headlamp range adjustment		√	√	√	√	√		
					Information and communication	MSS - Special vehicle multifunction control module		√	√	√				
						ICM - Instrument cluster with maintenance interval display		√	√	√	√	√		Oil change
						SCM[MRM] - Steering column module(As of model year 2002)		√	√	√	√	√		
						AGW - Audio gateway		√	√	√	√	√		
						COMAND/AUDIO - Audio50 or COMAND		√	√	√	√	√		Read coding and change if necessary
						CDC - CD changer		√	√	√	√			
						HFS - Hands free system and microphone		√	√	√				
					Seats and Doors	CTEL - Telephone adapter for portable CTEL		√	√	√	√	√		
						DCM-FL - Door control module front left		√	√	√	√	√		
						DCM-FR - Door control module front right		√	√	√	√	√		
						DCM-RL - Door control module rear left		√	√	√	√	√		
						DCM-RR - Door control module rear right		√	√	√	√	√		
					ESA driver - Electric seat adjustment front passenger(with memory)		√	√	√	√	√			

					ESA passenger - Electric seat adjustment front passenger(with memory)		√	√	√	√	√	
					AAC- Automatic air conditioning		√	√	√	√	√	
				Air conditioning	STH - Stationary heater with remote control		√	√	√	√	√	
					HSW - Heated steering wheel		√	√	√	√	√	
					ETC - Electronic transmission control		√	√	√	√	√	Initial startup Control unit adaptations Adaptations Diagnosis routiness
				Drive	ESM - Electronic selector module		√	√	√	√	√	
					ME-SFI 2.8 - Motor electronics 2.8		√	√	√	√	√	
					CDI 2 - Common Rail Diesel Injection		√	√	√	√	√	
					CDI-V1 - Common Rail Diesel Injection		√	√	√	√	√	
					VG - Transfer case		√	√	√	√	√	
				Chassis	ESP - Electronic stability program		√	√	√	√	√	Road test
					TPC - Tire pressure monitor		√	√	√	√	√	Read coding and change if necessary
					AB - Airbag		√	√	√	√	√	
					EIS - Electronic ignition switch		√	√	√	√	√	
					UCP - Upper control panel		√	√	√	√	√	
				Body	SAM-F - Signal acquisition and actuation module front		√	√	√	√	√	
					REAR SAM - Rear signal acquisition and actuation module		√	√	√	√	√	
					AHE - Trailer recognition		√	√	√	√	√	
					OCP - Overhead control panel		√	√	√	√	√	Read coding and change if necessary
					MSS - Special vehicle multifunction control module		√	√	√	√	√	
					ALWR - Headlamp range adjustment		√	√	√			
				Information and communication	ICM - Instrument cluster with maintenance interval display		√	√	√	√	√	Oil change
					SCM[MRM] - Steering column module(As of model year 2002)		√	√	√	√	√	
					AGW - Audio gateway		√	√	√	√	√	
					COMAND/AUDIO - Audio50 or COMAND		√	√	√	√	√	Read coding and change if necessary
					CDC - CD changer		√	√	√	√	√	
					HFS - Hands free system and microphone		√	√	√			
					CTEL - Telephone adapter for portable CTEL		√	√	√	√	√	
					DCM-FL - Door control module front left		√	√	√	√	√	



Mercedes	All	2006-2009	GL-CLASS	X164	Information and communication	IC - Instrument cluster		√	√	√	√	√	
						ASSYST - Active Service System		√	√	√	√		AssystSetting
						ASSYST PLUS - PLUS Active Service System		√	√	√	√		General servicing Control unit adaptations
						CM - Compass module		√	√	√	√		
						SCM - Steering column module		√	√	√	√	√	
						PTS - Parktronic system		√	√	√	√		
						AGW - Audio gateway(MOST network management,diagnosis gateway,radio tuner)		√	√	√	√	√	
						COMAND/AUDIO - Audio50 or COMAND		√	√	√	√		
						CDC - CD changer		√	√	√	√		
						TV - TV tuner(Not valid for Japan and USA)		√	√	√	√	√	
						CTEL - Telephone adapter for portable CTEL		√	√	√	√	√	
						Seats and doors	DCM-FL - Door control module front left		√	√	√	√	√
					DCM-FR - Door control module front right			√	√	√	√	√	
					REDC - Rear-end door closing control module			√	√	√	√	√	
					ESA driver - Electric seat adjustment driver(with memory)			√	√	√	√	√	
					ESA passenger - Electric seat adjustment front passenger(with memory)			√	√	√	√	√	
					DS-LF - Left front dynamic seat			√	√	√	√	√	
					DS-RF - Right front dynamic seat			√	√	√	√	√	
					DSP - Pneumatic pump for dynamic seat			√	√	√	√	√	
					ERA - Electric fold-down backrest system(3rd seat row)			√	√	√	√	√	
					HS - Seat heater			√	√	√			
					Air Conditioning		AAC - Automatic air conditioning		√	√	√	√	√
						STH - Stationary heater with remote control		√	√	√	√	√	
						HSW - Heated steering wheel		√	√	√	√	√	
					Drive	ME 9.7 - Motor electronics 9.7( Chassis CAN bus )		√	√	√	√	√	
						CDI 6 - Common Rail Diesel Injection( Chassis CAN bus )		√	√	√	√	√	
						FSCU - Fuel Pump( Drive train CAN bus )		√	√	√	√	√	
						Transmission		√	√	√	√	√	
						ESM - Electronic selector module( Drive train CAN bus )		√	√	√	√	√	



Mercedes	All	2008-2009	GLK	X204	Chassis	ABR - Adaptive Brake( Chassis CAN bus )	✓	✓	✓	✓		
						Suspension( Chassis CAN bus )	✓	✓	✓	✓	✓	
						TPC - Tire pressure monitor( Interior CAN bus )	✓	✓	✓	✓	✓	
					Body	CGW - Central gateway( Central CAN bus )	✓	✓	✓	✓		
						EZS - Electronic ignition switch( Interior CAN bus )	✓	✓	✓	✓		
						KG - Keyless Go( Interior CAN bus )	✓	✓	✓			
						XALWA-L - Xenon headlamp,left( Front end CAN bus )	✓	✓	✓	✓	✓	
						XALWA-R - Xenon headlamp,right( Front end CAN bus )	✓	✓	✓	✓	✓	
						AB - Airbag	✓	✓	✓	✓		
						WSS - Weight sensor system (USA)( Interior CAN bus )	✓	✓	✓			
						System 'Dr-side SAM' with connected LIN components( Interior CAN bus )	✓	✓	✓	✓	✓	
						System 'REAR SAM' with connected LIN components( Interior CAN bus )	✓	✓	✓	✓	✓	
						OCP - Overhead control panel( Interior CAN bus )	✓	✓	✓	✓	✓	
						COU[ZBE] - Central operating unit( Telematic CAN bus )	✓	✓	✓	✓	✓	
						RevETR-LF - Left front reversible emergency tensinoing retrator( Chassis CAN bus )	✓	✓	✓	✓		
						RevETR-RF - Right front reversible emergency tensinoing retrator( Chassis CAN bus )	✓	✓	✓	✓		
						Information and communication	ICM - Instrument cluster with maintenance interval display( Interior CAN bus )	✓	✓	✓	✓	✓
					SCM[MRM] - Steering column module( Chassis CAN bus )		✓	✓	✓	✓	✓	
					PTS - Parktronic( Interior CAN bus )		✓	✓	✓	✓	✓	
					RFK - Backup camera Janpan( Interior CAN bus )		✓	✓	✓	✓		
					COMAND - COMAND with integral telematics gateway(MOST network management, diagnosis gateway)		✓	✓	✓	✓	✓	
					Tuner - Radio tuner with amplifier		✓	✓	✓			
					CTEL - Mobile telephone adapter with universal interface		✓	✓	✓	✓	✓	
					VCS - Voice control(Linguatronic)	✓	✓	✓	✓	✓		

					TV - TV tuner(Not valid for Japan and USA)		√	√	√	√		
					SDAR - Satellite radio (Valid for USA)		√	√	√	√	√	
					ZAN - Central Display		√	√	√	√	√	
					COU[ZBE] - Central operating unit( Telematic CAN bus )		√	√	√	√	√	
					KBE-H -Rear A/C operating unit		√	√	√	√		
				Seats and Doors	System 'Door control module front left' with connected LIN components( Interior CAN bus )		√	√	√	√	√	
					System 'Door control module front right' with connected LIN components( Interior CAN bus )		√	√	√	√	√	
					DCM-RL - Door control module rear left( Interior CAN bus )		√	√	√	√	√	
					DCM-RR - Door control module rear right( Interior CAN bus )		√	√	√	√	√	
					ESA driver - Electric seat adjustment driver( Interior CAN bus )		√	√	√	√	√	
				Air conditioning	AAC - Automatic air conditioning( Interior CAN bus )		√	√	√	√	√	
Mercedes	All	1996-2003	VITO/V-CLASS	638	ME2 - Fuel injection and ignition system		√	√	√	√		
					V6 - 6-cylinder gasoline engine		√	√	√	√		
					CDI - Common rail diesel injection		√	√	√	√	√	
					ABS - Anti-lock brake system		√	√	√	√		
					WSP - Immobilizer		√	√	√	√		
					AB - Airbag		√	√	√	√		
					AG - Automatic transmission for V6 engines		√	√	√	√		
					AGN - Automatic transmission		√	√	√	√		
					KR - Combination relay		√	√	√	√		
					HZR - Heating control		√	√	√	√		
					ATA - Anti-theft alarm system		√	√	√	√	√	
					ENR - Electronic level control		√	√	√			
					ERE - Electronic inline		√	√	√	√	√	
					EVE - Evecronic distributor injection		√	√	√	√	√	
					APS - Auto pilot system		√	√	√			
KI - Instrument cluster		√	√	√	√							

Mercedes	All	2004-2007	VITO/VIA NO	639	Drive	ETC - Electronic transmission control	✓	✓	✓	✓	✓	Initial startup Control unit adaptations Learn air conditioning Adaptations Diagnosis routiness Read coding and/or transfer download to new control unit
						ESM - Electronic selector module	✓	✓	✓	✓	✓	
						ME-SFI - Motor electronics	✓	✓	✓	✓	✓	
						CDI - Common Rail	✓	✓	✓	✓	✓	
					Chassis	ENR - Electronic level control	✓	✓	✓			
						ESP - Electronic stability program	✓	✓	✓	✓		
						TPC - Tire pressure monitor	✓	✓	✓			
					Body	AAG - Trailer connection unit	✓	✓	✓			
						OCP - Overhead control panel	✓	✓	✓	✓		
						EIS - Electronic ignition switch	✓	✓	✓	✓		
						CGW - Central gateway	✓	✓	✓			
						UCP - Upper control panel	✓	✓	✓	✓	✓	
						SAM - Signal acquisition and actuation module	✓	✓	✓	✓	✓	
						SDE-H - Rear sliding/tilting sunroof unit	✓	✓	✓	✓	✓	
					Information and Communication	SRS - Supplemental restraint system	✓	✓	✓	✓		
						IC - Instrument cluster	✓	✓	✓	✓	✓	
						PTS - Parktronic system	✓	✓	✓			
						AGW Audio gateway(MOST master),COMAND,AUDIO,SOUND	✓	✓	✓	✓	✓	
					Seats and doors	ESA passenger - Electric seat adjustment passenger	✓	✓	✓			
						ESA driver - Electric seat adjustment driver	✓	✓	✓			
DCM-FL - Door control module front left	✓	✓	✓	✓		✓						
DCM-FR - Door control module front right	✓	✓	✓	✓		✓						
Air Conditioning	AAC - Automatic air conditioning/automatic temperature control/Heating-ventilation	✓	✓	✓	✓	✓	Control unit reset Perform normalizing of component M16/8(Blending air flap actuator motor)					
	PTC - Electric heater booster	✓	✓	✓	✓	✓	Control unit reset					
	REAR AC - Rear air conditioning/Rear heater	✓	✓	✓	✓	✓						
	STH - Stationary heater/Heater booster	✓	✓	✓	✓	✓						
							ECM - Engine control monolith	✓	✓	✓	✓	

Mercedes	All	2002-2005	VANEO	414	Drive	ACS - Automatic clutch system		√	√	√	√	√	
						FTC - Front transmission control		√	√	√	√	√	
						ESM - Electronic selector module		√	√	√	√	√	
						CDI - Common Rail		√	√	√			
					Chassis	ESP - Electronic stability program		√	√	√	√		
						Body	AB - Airbag		√	√	√	√	√
					ATA - Anti-theft alarm system			√	√	√	√	√	
					DAS - Drive authorization system			√	√	√	√	√	
					Information and Communication	ICM - Instrument cluster with maintenance interval display		√	√	√	√	√	
						PTS - Parktronic system		√	√	√	√	√	
						D2B - AUDIO		√	√	√	√	√	
						CDC - CD changer		√	√	√			
						CTEL - Cellular telephone 1(fixed installation or portable)(D2B)		√	√	√			
					Seats and doors	CL - Central locking		√	√	√	√	√	
					Air Conditioning	TAC - Automatic temperature control		√	√	√			
						STH - Stationary heater		√	√	√	√	√	
Mercedes	All	2006-2009	Sprinter	906	Drive	ETC - Electronic transmission control		√	√	√	√		
						ESM - Electronic selector module		√	√	√	√	√	
						ME Motor electronics(4 Cylinder ,M271)		√	√	√	√	√	
						CDI4 Common Rail Diesel Injection(EURO4,EU4)		√	√	√	√	√	
						VG Transfer case		√	√	√	√	√	
					Chassis	ENR - Electronic level control		√	√	√			
						ESP - Electronic stability program		√	√	√	√		
					Body	EIS - Electronic ignition switch		√	√	√	√		
						KE - Keyless Entry		√	√	√	√	√	
						HRA - Headlamp range adjustment		√	√	√	√	√	
						SCM - Steering column module		√	√	√	√	√	
						UCP - Upper control panel		√	√	√	√	√	
						SAM - Signal acquisition and actuation module		√	√	√	√	√	
						SRS - Supplemental restraint system		√	√	√	√		Reset ECU
					CDC - CD changer		√	√	√	√			

					Information and Communication	KI - Instrument cluster	✓	✓	✓	✓	✓	Reset of maintenance interval display (Oil change)
						NAVI - Navigation system	✓	✓	✓	✓		
						PTS - Parktronic system	✓	✓	✓	✓		
						RADIO Sound5	✓	✓	✓	✓	✓	
						TEL Telephone control unit	✓	✓	✓	✓	✓	
					Seats and doors	TSG Door control module	✓	✓	✓	✓	✓	
					Air Conditioning	AAC - Automatic air conditioning/automatic temperature control/Heating-ventilation	✓	✓	✓			
Mercedes	All	2000-2006	Sprinter	901.6,902.6,903.6,904.6,905.6		CR - Common rail	✓	✓	✓	✓		
						ME - Fuel injection and ignition system	✓	✓	✓	✓		
						KI - Instrument cluster	✓	✓	✓	✓	✓	
						WSP - Immobilizer	✓	✓	✓	✓		
						AB - Airbag	✓	✓	✓	✓		
						ABS - Anti-lock brake system	✓	✓	✓	✓		
						ESP - Electronic Stability Program	✓	✓	✓	✓	✓	
						HZR heating control	✓	✓	✓			
						SSG Sprintsift transmission	✓	✓	✓	✓	✓	
						Radio	✓	✓	✓	✓	✓	
Mercedes	All	2000-2006	Sprinter	901.0/3/4,902.0/3/4,903.0/3/4,904.0/3/4		ME - Fuel injection and ignition system	✓	✓	✓	✓		
						V6 - 6-cylinder gasoline engine	✓	✓	✓	✓		
						CDI - Common rail diesel injection	✓	✓	✓	✓		
						KI - Instrument cluster	✓	✓	✓	✓	✓	
						ABS - Anti-lock brake system	✓	✓	✓	✓		
						WSP - Immobilizer	✓	✓	✓	✓		
						AB - Airbag	✓	✓	✓	✓	✓	
						AG - Automatic transmission for V6 engines	✓	✓	✓	✓		
						AGN - Automatic transmission	✓	✓	✓	✓		
						KR - Combination relay	✓	✓	✓	✓		
						HZR - Heating control	✓	✓	✓			
						ATA - Anti-theft alarm system	✓	✓	✓	✓	✓	
						ENR - Electronic level control	✓	✓	✓			
						ERE - Electronic inline	✓	✓	✓	✓	✓	
	APS - Auto pilot system	✓	✓	✓								

Mercedes	All	2000-2006	Sprinter	690.6	CR - Common rail		√	√	√	√		
					ME - Fuel injection and ignition system		√	√	√	√		
					KI - Instrument cluster		√	√	√	√	√	
					WSP - Immobilizer		√	√	√	√		
					AB - Airbag		√	√	√	√		
					ABS - Anti-lock brake system		√	√	√	√	√	
					ESP - Electronic Stability Program		√	√	√	√	√	
					HZR heating control		√	√	√			
					SSG Sprintshift transmission		√	√	√			
					Radio		√	√	√	√	√	