

How to read this list:	
Mark	Description
√	Function is supported.
*	Function is added or developed newly

V30/PC-MAX Function List										
Automaker:		Peugeot								
Software		V5.5								
Automaker	Model	Vehicle Type	ECU Type	System	Sys. Info.	Read Code	Clear Code	Data Stream	Actuations	Special Functions
Peugeot	106R		CDY BOSCH MA3.1	Petrol Engine	√	√	√	√	√	
Peugeot	106R		CDZ BOSCH MA3.1	Petrol Engine	√	√	√	√	√	
Peugeot	106R		HDY BOSCH MA3.1	Petrol Engine	√	√	√	√	√	
Peugeot	106R		HDZ BOSCH MA3.1	Petrol Engine	√	√	√	√	√	
Peugeot	106R		HFX BOSCH M7.4.4	Petrol Engine	√	√	√	√	√	
Peugeot	106R		KFX BOSCH MP7.3	Petrol Engine	√	√	√	√		
Peugeot	106R		KFX MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	106R		NFX MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	106R		KFW SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		NFU BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		RFR MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		N6A BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		RFN MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		KFX BOSCH MP7.3	Petrol Engine	√	√	√	√		
Peugeot	206		KFX MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	206		KFU MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	206		RFN MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	206		HFY MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	206		HFZ MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	206		RFK MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	206		N6A BOSCH ME7.4.5	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		NFU BOSCH ME7.4.5	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		KFW SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

Peugeot	206		K6D SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		KFW BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		7LZ MM5NP	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		N6A BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	√	√	√	√	√	
Peugeot	206		NFU BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		KFW BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		KFW J34P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		K6D J34P	Petrol Engine	√	√	√	√	√	
Peugeot	206		NFU or N6A or N6B ME7.4.9 FLEX FUEL	Petrol Engine	√	√	√	√	√	
Peugeot	206		NFU J35	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		K6C MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	206		HFX MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		WJY LUCAS DCN2	Diesel Engine	√	√	√	√		
Peugeot	206		WJZ LUCAS DCN2	Diesel Engine	√	√	√	√		
Peugeot	206		RHY BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	*Particle filter regeneration
Peugeot	206		9HZ BOSCH EDC16C3	Diesel Engine	√	√	√	√	√	*Particle filter regeneration
Peugeot	206		8HX/8HZ BOSCH EDC16C3 EURO3	Diesel Engine	√	√	√	√	√	
Peugeot	206		8HZ BOSCH EDC16C3 EURO4	Diesel Engine	√	√	√	√	√	
Peugeot	206		9HY BOSCH EDC16C3 EURO4	Diesel Engine	√	√	√	√	√	
Peugeot	206		ABS BOSCH 5.3	ABS	√	√	√	√	√	Bleeding
Peugeot	206		ABS MK70	ABS	√	√	√	√	√	Bleeding
Peugeot	206		ABS TEVES	ABS	√	√	√	√	√	
Peugeot	206		ESP MK60	ABS	√	√	√	√		Bleeding
Peugeot	206		Auto Gearbox AL4	AT	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		BVA AL4	AT	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206		Airbag and seatbelts	Airbag	√	√	√			
Peugeot	206		Left side airbag	Airbag	√	√	√			
Peugeot	206		Right side airbag	Airbag	√	√	√			
Peugeot	206		SAC-CENT-AUTOLIV-2	Airbag	√	√	√			
Peugeot	206		BSI	Built-In System	√	√	√	√	√	1.Forcing of the customer mode 2.Resetting to zero of the service mileage 3.Configuration
Peugeot	206		BIS_SIEMENS	Built-In System	√	√	√	√	√	
Peugeot	206		AMF	Multi-function display	√	√	√	√	√	
Peugeot	206		AUTORADIO	Radio	√	√	√	√	√	

Peugeot	206		COMBINE_MM	Instrument panel	√	√	√	√	√	
Peugeot	206		COM2000	Steering wheel switching module	√	√	√	√		
Peugeot	206		ALARME_TEXTON	Alarm	√	√	√			
Peugeot	206			On-board navigation system	√	√	√	√	√	
Peugeot	206		CLIM_T12001	Air Conditioning	√	√	√	√	√	
Peugeot	206			Driving school	√			√	√	
Peugeot	206		CPT_PLUIE_LUM	Rain/brightness sensor	√	√	√			
Peugeot	206			Diesel fuel additive control unit	√	√	√	√	√	
Peugeot	206		TOUV_TEXTON	Sun roof	√	√	√	√	√	
Peugeot	206 MUX		NFU BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		RFR MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		N6A BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		RFN MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		KFX BOSCH MP7.3	Petrol Engine	√	√	√	√		
Peugeot	206 MUX		KFX MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		KFU MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		RFN MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		HFY MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		HFZ MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		RFK MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		N6A BOSCH ME7.4.5	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		NFU BOSCH ME7.4.5	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		KFW SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		K6D SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		KFW BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		7LZ MM5NP	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		N6A BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		NFU BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		KFW BOSCH ME7.4.4 FLEX FUEL	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		KFW J34P	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		K6D J34P	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		NFU OF N6A OF N6B ME7.4.5 FLEX FUEL	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		NFU J35	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		K6C MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	206 MUX		HFX MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		WJY LUCAS DCN2	Diesel Engine	√	√	√	√		

Peugeot	206 MUX		WJZ LUCAS DCN2	Diesel Engine	√	√	√	√		
Peugeot	206 MUX		RHY BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	*Particle filter regeneration
Peugeot	206 MUX		9HZ BOSCH EDC16C3	Diesel Engine	√	√	√	√	√	*Particle filter regeneration
Peugeot	206 MUX		8HX/8HZ BOSCH EDC16C3 EURO3	Diesel Engine	√	√	√	√	√	
Peugeot	206 MUX		8HZ BOSCH EDC16C3 EURO4	Diesel Engine	√	√	√	√	√	
Peugeot	206 MUX		9HY BOSCH EDC16C3 EURO4	Diesel Engine	√	√	√	√	√	
Peugeot	206 MUX		ABS BOSCH 5.3	ABS	√	√	√	√	√	Bleeding
Peugeot	206 MUX		ABS MK70	ABS	√	√	√	√	√	Bleeding
Peugeot	206 MUX		ABS TEVES	ABS	√	√	√	√		
Peugeot	206 MUX		ESP MK60	ABS	√	√	√	√	√	Bleeding
Peugeot	206 MUX		TEVES_MK20E	ABS	√	√	√	√	√	Bleeding
Peugeot	206 MUX		Auto Gearbox AL4	AT	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		BVA AL4	AT	√	√	√	√	√	Initialising the autoada ptives
Peugeot	206 MUX		Airbag and seatbelts	Airbag	√	√	√			
Peugeot	206 MUX		Left side airbag	Airbag	√	√	√			
Peugeot	206 MUX		Right side airbag	Airbag	√	√	√			
Peugeot	206 MUX		SAC-CENT-AUTOLIV-2	Airbag	√	√	√			
Peugeot	206 MUX		BSI	Built-In System	√	√	√	√	√	1.Forcing of the customer mode 2.Resetting to zero of the service mileage 3.Configuration
Peugeot	206 MUX		BIS_SIEMENS	Built-In System	√	√	√	√	√	
Peugeot	206 MUX		AMF	Multi-function display	√	√	√	√	√	
Peugeot	206 MUX		AUTORADIO	Radio	√	√	√	√	√	
Peugeot	206 MUX		COMBINE_MM	Instrument panel	√	√	√	√	√	
Peugeot	206 MUX		COM2000	Steering wheel switching module	√	√	√	√		
Peugeot	206 MUX		ALARME_TEXTON	Alarm	√	√	√			
Peugeot	206 MUX			On-board navigation system	√	√	√	√		
Peugeot	206 MUX		CLIM_T12001	Air Conditioning	√	√	√	√	√	
Peugeot	206 MUX			Driving school	√			√	√	
Peugeot	206 MUX		CPT_PLUIE_LUM	Rain/brightness sensor	√	√	√			
Peugeot	206 MUX			Diesel fuel additive control unit	√	√	√	√	√	
Peugeot	206 MUX		TOUV_TEXTON	Sun roof	√	√	√	√	√	
Peugeot	306		HDY BOSCH MA3.1	Petrol Engine	√	√	√	√	√	
Peugeot	306		HDZ BOSCH MA3.1	Petrol Engine	√	√	√	√	√	
Peugeot	306		KFX MM1AP	Petrol Engine	√	√	√	√	√	

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

Peugeot	306		RFS MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	306R		KFX BOSCH MP7.3	Petrol Engine	√	√	√	√		
Peugeot	306R		KFX MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	306R		KFX SAGEM SL96	Petrol Engine	√	√	√	√		
Peugeot	306R		LFY BOSCH MP7.3	Petrol Engine	√	√	√	√		
Peugeot	306R		LFY SAGEM SL96	Petrol Engine	√	√	√	√		
Peugeot	306R		NFT BOSCH M7.4.4	Petrol Engine	√	√	√	√	√	
Peugeot	306R		NFV BOSCH M7.4.4	Petrol Engine	√	√	√	√	√	
Peugeot	306R		RFS MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	306R		KFW SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	306R		K6D SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	306R		WJY LUCAS DCN2	Diesel Engine	√	√	√	√		
Peugeot	306R		WJZ LUCAS DCN2	Diesel Engine	√	√	√	√		
Peugeot	306R		RHY BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	306R			ABS	√	√	√	√	√	Bleeding
Peugeot	306R			Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	306R		Airbag and seatbelts	Airbag	√	√	√			
Peugeot	306R		Left side airbag	Airbag	√	√	√			
Peugeot	306R		Right side airbag	Airbag	√	√	√			
Peugeot	306R		CPH_TEXTON	Built-In System	√	√	√	√		
Peugeot	307 VAN		NFU BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	307 VAN		N6A BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	307 VAN		KFU MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	307 VAN		RFN MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	307 VAN		RFK MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	307 VAN		N6A BOSCH ME7.4.5	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	307 VAN		NFU BOSCH ME7.4.5	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	307 VAN		KFW SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	307 VAN		RFN MM48P(Mechanical throttle housing)	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	307 VAN			Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	307 VAN		K6D SAGEM S2000	Petrol Engine	√	√	√	√	√	
Peugeot	307 VAN		RHZ BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	307 VAN		RHS BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	*Particle filter regeneration
Peugeot	307 VAN		RHY BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	*Particle filter regeneration
Peugeot	307 VAN		8HZ BOSCH EDC16C3	Diesel Engine	√	√	√	√	√	
Peugeot	307 VAN		9HX BOSCH EDC16C3	Diesel Engine	√	√	√	√	√	

Peugeot	307 VAN		9HZ BOSCH EDC16C3	Diesel Engine	√	√	√	√	√	*1.Particle filter regeneration(stationary) 2.Particle filter regeneration(moving)
Peugeot	307 VAN		RHY SIEMENS SID 801	Diesel Engine	√	√	√	√	√	
Peugeot	307 VAN		9HY BOSCH EDC16C3 EURO4	Diesel Engine	√	√	√	√	√	
Peugeot	307 VAN		RHL SIEMENS SID 803	Diesel Engine	√	√	√	√	√	*1.Particle filter regeneration(stationary) 2.Particle filter regeneration(moving)
Peugeot	307 VAN		RHR SIEMENS SID 803	Diesel Engine	√	√	√	√	√	*1.Particle filter regeneration(stationary) 2.Particle filter regeneration(moving)
Peugeot	307 VAN		ABS8_BOSCH	ABS	√	√	√	√	√	Bleeding
Peugeot	307 VAN		ESP BOSCH 8	ABS	√	√	√	√	√	Bleeding
Peugeot	307 VAN		ESP BOSCH 5.7	ABS	√	√	√	√	√	Bleeding
Peugeot	307 VAN		TEVES_MK60_ABS	ABS	√	√	√	√		
Peugeot	307 VAN		ABS BOSCH 5.3	ABS	√	√	√	√	√	Bleeding
Peugeot	307 VAN		ABS BOSCH 8	ABS	√	√	√	√		
Peugeot	307 VAN		Auto Gearbox 4PH20	AT	√	√	√	√	√	Initialising the autoada ptives
Peugeot	307 VAN		BVA AL4	AT	√	√	√	√	√	Initialising the autoada ptives
Peugeot	307 VAN		SAC_Central	Airbag	√	√	√	√		
Peugeot	307 VAN		SAC_CENT_SIEMENS	Airbag	√	√	√	√		
Peugeot	307 VAN		CLIM T5	Air Conditioning	√	√	√	√	√	
Peugeot	307 VAN		BSI	Built-In System	√	√	√	√	√	1.Forcing of the customer mode 2.Resetting to zero of the service mileage
Peugeot	307 VAN		AMF	Multi-function display	√	√	√	√	√	
Peugeot	307 VAN		AUTORADIO	Radio	√	√	√	√	√	
Peugeot	307 VAN		CHANGEUR_CD	CD Player	√	√	√	√	√	
Peugeot	307 VAN		COMBINE_SAGEM	Instrument Panel	√	√	√	√	√	
Peugeot	307 VAN		GEP	Power Steering	√	√	√	√		
Peugeot	307 VAN		COM2000	Steering wheel switching module	√	√	√	√		
Peugeot	307 VAN		ALARME_TEXTON	Alarm	√	√	√			
Peugeot	307 VAN		TO_WEBASTO	Sun roof	√	√	√	√	√	

Peugeot	307 VAN		TOUV_TEXTON	Sun roof	√	√	√	√	√	
Peugeot	307 VAN		MDP_CONDUCT	Driver's door module	√	√	√	√		
Peugeot	307 VAN		MDP_PASSAG	Passenger door module	√	√	√	√		
Peugeot	307 VAN		BRET	Roll-over ECU	√	√	√	√		
Peugeot	307 VAN			Diesel fuel additive control unit	√	√	√	√	√	
Peugeot	307 VAN			Driving school	√			√	√	
Peugeot	307 CAN		RFJ MM6LPB	Petrol Engine	√	√	√	√	√	
Peugeot	307 CAN		KFU MM6LP	Petrol Engine	*	*	*	*	*	
Peugeot	307 CAN		RFK MM6LP	Petrol Engine	*	*	*	*	*	
Peugeot	307 CAN		RFN MM6LP	Petrol Engine	*	*	*	*	*	
Peugeot	307 CAN		N6A BOSCH ME7.4.5	Petrol Engine		*	*	*	*	
Peugeot	307 CAN		NFU BOSCH ME7.4.5	Petrol Engine		*	*	*	*	
Peugeot	307 CAN		9HZ BOSCH EDC 16C34 Common Rail	Desel Engine		√	√	√	√	1.EGR throttle learning *2.Particle filter regeneration
Peugeot	307 CAN		9HW BOSCH EDC 16C34	Desel Engine		*	*	*	*	*1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	307 CAN		9HX BOSCH EDC 16C34	Desel Engine		*	*	*	*	*1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration

Peugeot	307 CAN		9HY BOSCH EDC 16C34	Desel Engine		*	*	*	*	*1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	307 CAN		2.0 SIMENS HDI SID803A[RHR]	Desel Engine		*	*	*	*	*1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	307 CAN			ABS/ESP	√	√	√	√	√	
Peugeot	307 CAN			Automatic transmission control unit	√	√	√	√	√	
Peugeot	307 CAN			Air bag	√	√	√	√	√	
Peugeot	307 CAN			Air Conditioning	√	√	√	√	√	
Peugeot	307 CAN			Built-In System	√	√	√	√	√	Resetting_zero_service
Peugeot	307 CAN			Multi-function display	√	√	√	√	√	
Peugeot	307 CAN			Instrument Panel	√	√	√	√	√	
Peugeot	307 CAN			Steering wheel switching module	√	√	√	√	√	
Peugeot	307 CAN			Alarm	√	√	√	√	√	
Peugeot	307 CAN			Driver's door module	√	√	√	√	√	
Peugeot	307 CAN			Passenger door module	√	√	√	√	√	
Peugeot	307 CAN			Rain/brightness sensor	√	√	√			
Peugeot	307 CAN			Parking assistance	√	√	√	√	√	
Peugeot	307 CAN			CD Player	√	√	√		√	
Peugeot	307 CAN			Power Steering	√	√	√	√		
Peugeot	307 CAN			Hand Free Kit	√	√	√	√	√	
Peugeot	406		KFX SAGEM SL96	Petrol Engine	√	√	√	√		
Peugeot	406		XFX BOSCH ME7.4.6	Petrol Engine	√	√	√	√	√	
Peugeot	406		3FZ MM4MP2	Petrol Engine	√	√	√	√		Initialising the autoada ptives
Peugeot	406		RFR MM4.8P	Petrol Engine	√	√	√	√	√	
Peugeot	406		RLZ SIEMENS SIRIUS 81	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406		LFY BOSCH MP7.3	Petrol Engine	√	√	√	√		Initialising the autoada ptives
Peugeot	406		LFY SAGEM SL96	Petrol Engine	√	√	√	√		
Peugeot	406		LFX MM1AP	Petrol Engine	√	√	√	√	√	



Peugeot	406		RHZ BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406		RHY BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406			ABS	√	√	√	√	√	Bleeding
Peugeot	406			Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406		Airbag and seatbelts	Airbag	√	√	√			
Peugeot	406		Left side airbag	Airbag	√	√	√			
Peugeot	406		Right side airbag	Airbag	√	√	√			
Peugeot	406R		KFX SAGEM SL96	Petrol Engine	√	√	√	√		
Peugeot	406R		XFX BOSCH ME7.4.6	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		3FZ MM4MP2	Petrol Engine	√	√	√	√		
Peugeot	406R		RFR MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		RLZ SIEMENS SIRIUS 81	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		LFY BOSCH MP7.3	Petrol Engine	√	√	√	√		
Peugeot	406R		R6F MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		LFY SAGEM SL96	Petrol Engine	√	√	√	√		
Peugeot	406R		LFX MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	406R		RLZ IDE SIRIUS 81	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		6FZ SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		RFN MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		RHZ BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406R		RHY BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406R		RHS BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406R		RHY SIEMENS SID 801	Diesel Engine	√	√	√	√	√	
Peugeot	406R		4HX BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406R		ABR5.3	ABS	√	√	√	√	√	Bleeding
Peugeot	406R		BVA_AL4	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		BVA_AL41	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		Auto Gearbox 4HP20	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		Auto Gearbox AL4	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R		BVA_ZF	Auto Gearbox	√	√	√	√	√	
Peugeot	406R		SAC_ACK	Airbag	√	√	√	√		
Peugeot	406R		SAC_CENT_AUTOLIV_2	Airbag	√	√	√			
Peugeot	406R		BSI	Built-in system interface	√	√	√	√	√	
Peugeot	406R		BSI_SIEMENS	Built-in system interface	√	√	√	√	√	
Peugeot	406R		CLIM_D92001	Air Conditioning	√	√	√	√	√	
Peugeot	406R		CLIM_D9	Air Conditioning	√	√	√	√	√	
Peugeot	406R		AMF	Multi-function display	√	√	√	√	√	
Peugeot	406R		AUTORADIO	Radio	√	√	√	√	√	
Peugeot	406R		COMBINE_VDO	Instrument panel	√	√	√	√	√	

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

Peugeot	406R		SIEGE_BITRON	Seat and mirrors with memory	√	√	√	√		
Peugeot	406R			Alarm	√	√	√			
Peugeot	406R		DVA_ZF	Power Steering	√	√	√			
Peugeot	406R		CD player	CD player	√	√	√	√	√	
Peugeot	406R			On-board navigation system	√	√	√	√		
Peugeot	406R			Diesel fuel additive control unit	√	√	√	√		
Peugeot	406R			Rain/brightness sensor	√	√	√			
Peugeot	607		3FZ MM4MP2	Petrol Engine	√	√	√	√		
Peugeot	607		R6F MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	607		RFN MM48P(Mechanical throttle housing)	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	607		XFZ BOSCH ME7.4.6	Petrol Engine	√	√	√	√	√	
Peugeot	607		RHZ BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	607		RHS BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	607		4HX BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	607			ABS	√	√	√	√	√	Bleeding
Peugeot	607			Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	607			Airbag	√	√	√			
Peugeot	607			Air Conditioning	√	√	√	√		
Peugeot	806		R6F MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	806		RFN MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	806		RHZ BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	806		RHW BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	806		Airbag and seatbelts	Airbag	√	√	√	√	√	
Peugeot	806		BOSCH ABS 5.3	ABS	√	√	√			Bleeding
Peugeot	807 VAN		3FZ MM4MP2	Petrol Engine	√	√	√	√		
Peugeot	807 VAN		3FZ MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	807 VAN		RFN MM6LP	Petrol Engine	√	√	√	√	√	
Peugeot	807 VAN		XFW BOSCH ME746	Petrol Engine	√	√	√	√		
Peugeot	807 VAN		R6F MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	807 VAN		RFN MM48P(Mechanical throttle housing)	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	807 VAN		RHW BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	807 VAN		RHT BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	807 VAN		RHM BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	807 VAN		4HW BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	

Peugeot	807 VAN		ESP BOSCH 5.7	ABS	√	√	√	√	√	Bleeding
Peugeot	807 VAN		BVA_AL4	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	807 VAN		4PH20 automatic gearbox	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	807 VAN			Airbag	√	√	√			
Peugeot	807 VAN		Climate control	Air Conditioning	√	√	√	√	√	
Peugeot	807 VAN			Multi-function display	√	√	√	√	√	
Peugeot	807 VAN			Instrument panel	√	√	√	√	√	
Peugeot	807 VAN			Steering wheel switching module	√	√	√	√		
Peugeot	807 VAN			Alarm	√	√	√			
Peugeot	807 VAN		AUTORADIO	Radio	√	√	√	√	√	
Peugeot	807 VAN			Driver's door module	√	√	√	√		
Peugeot	807 VAN			Passenger door module	√	√	√	√		
Peugeot	807 VAN			CD player	√	√	√	√	√	
Peugeot	807 VAN			Diesel fuel additive control unit	√	√	√	√	√	
Peugeot	PARTNER		HDY BOSCH MA3.1	Petrol Engine	√	√	√	√	√	
Peugeot	PARTNER		HDZ BOSCH MA3.1	Petrol Engine	√	√	√	√	√	
Peugeot	PARTNER		HFX BOSCH M7.4.4	Petrol Engine	√	√	√	√	√	
Peugeot	PARTNER		KFX BOSCH MP7.3	Petrol Engine	√	√	√	√	√	
Peugeot	PARTNER		KFX MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	PARTNER		KFX SGEAM SL96	Petrol Engine	√	√	√	√	√	
Peugeot	PARTNER		LFX MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	PARTNER		N6A BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	PARTNER		NFU BOSCH ME7.4.4	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	PARTNER		K6D SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	PARTNER		KFW SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	PARTNER		N6A BOSCH ME7.4.5	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	PARTNER		NFU BOSCH ME7.4.5	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	PARTNER		N6B BOSCH ME7.4.5	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	PARTNER		KFW J34P	Petrol Engine	√	√	√	√	√	
Peugeot	PARTNER		KFW SAGEM S2000PM1	Petrol Engine	√	√	√	√	√	
Peugeot	PARTNER		HFX MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	PARTNER		WJY LUCAS DCN2	Diesel Engine	√	√	√	√		
Peugeot	PARTNER		WJZ LUCAS DCN2	Diesel Engine	√	√	√	√		
Peugeot	PARTNER		RHY BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	PARTNER		RHY SIEMENS SID 801	Diesel Engine	√	√	√	√	√	
Peugeot	PARTNER		9HX BOSCH EDC16C3	Diesel Engine	√	√	√	√	√	
Peugeot	PARTNER		9HW BOSCH EDC16C3	Diesel Engine	√	√	√	√	√	

Peugeot	PARTNER		ALARME_TEXTON	Alarm	√	√	√			
Peugeot	PARTNER		COM2000	Steering wheel switching module	√	√	√	√		
Peugeot	PARTNER		AUTORADIO	Radio	√	√	√	√	√	
Peugeot	PARTNER		COMBINE_MM	Instrument panel	√	√	√	√	√	
Peugeot	PARTNER		BSI	Built-in system interface(BSI)	√	√	√	√	√	
Peugeot	PARTNER		BSI1	Built-in system interface(BSI)	√	√	√	√	√	1.Forcing of the customer mode 2.Resetting to zero of the service mileage
Peugeot	PARTNER		ESP BOSCH 5.7	ABS	√	√	√	√	√	Bleeding
Peugeot	PARTNER		ABS BOSCH 8	ABS	√	√	√	√	√	Bleeding
Peugeot	PARTNER		ESP BOSCH 8	ABS	√	√	√	√	√	Bleeding
Peugeot	PARTNER		ABS 8.1	ABS	√	√	√	√	√	Bleeding
Peugeot	PARTNER		Airbag and seatbelts	Airbag	√	√	√	√		
Peugeot	PARTNER		SAC_CENT_AUTOLIV	Airbag	√	√	√			
Peugeot	PARTNER			Display/Telematics	√	√	√	√	√	
Peugeot	PARTNER			CD player	√	√	√	√	√	
Peugeot	PARTNER			Rain/brightness sensor	√	√	√			
Peugeot	EXPERT		R6F MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	EXPERT		RFN MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	EXPERT		RHZ BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	EXPERT		WJY LUCAS DCN2	Diesel Engine	√	√	√	√		
Peugeot	EXPERT		RHW BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	EXPERT		RHX BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	EXPERT		BOSCH ABS5.3	ABS	√	√	√	√	√	Bleeding
Peugeot	EXPERT		BOSCH ABS5.3	Airbag	√	√	√			
Peugeot	BOXER			Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	BOXER		MM48P 2L essence plombée	ABS	√	√	√	√	√	Bleeding
Peugeot	406R Coupe		KFX SAGEM SL96	Petrol Engine	√	√	√	√		
Peugeot	406R Coupe		XFX BOSCH ME7.4.6	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		3FZ MM4MP2	Petrol Engine	√	√	√	√		
Peugeot	406R Coupe		RFR MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		RLZ SIEMENS SIRIUS 81	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		LFY BOSCH MP7.3	Petrol Engine	√	√	√	√		
Peugeot	406R Coupe		R6F MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		LFY SAGEM SL96	Petrol Engine	√	√	√	√		

Peugeot	406R Coupe		LFX MM1AP	Petrol Engine	√	√	√	√	√	
Peugeot	406R Coupe		RLZ IDE SIRIUS 81	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		6FZ SAGEM S2000	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		RFN MM4.8P	Petrol Engine	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		RHZ BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406R Coupe		RHY BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406R Coupe		RHS BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406R Coupe		RHY SIEMENS SID 801	Diesel Engine	√	√	√	√	√	
Peugeot	406R Coupe		4HX BOSCH EDC15C2	Diesel Engine	√	√	√	√	√	
Peugeot	406R Coupe		ABS ABR5.3	ABS	√	√	√	√	√	Bleeding
Peugeot	406R Coupe		BVA_AL4	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		BVA_AL41	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		Auto Gearbox 4HP20	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		Auto Gearbox AL4	Auto Gearbox	√	√	√	√	√	Initialising the autoada ptives
Peugeot	406R Coupe		Auto Gearbox	Auto Gearbox	√	√	√	√	√	
Peugeot	406R Coupe		BVA_ZF	Auto Gearbox	√	√	√	√	√	
Peugeot	406R Coupe		SAC_ACK	Airbag	√	√	√	√		
Peugeot	406R Coupe		SAC_CENT_AUTOLIV_2	Airbag	√	√	√			
Peugeot	406R Coupe		BSI	Built-in system interface	√	√	√	√	√	
Peugeot	406R Coupe		BSI_SIEMENS	Built-in system interface	√	√	√	√	√	
Peugeot	406R Coupe		CLIM_D92001	Air Conditioning	√	√	√	√	√	
Peugeot	406R Coupe		CLIM_D9	Air Conditioning	√	√	√	√	√	
Peugeot	406R Coupe		AMF	Multi-function display	√	√	√	√	√	
Peugeot	406R Coupe		AMF1	Multi-function display	√	√	√	√	√	
Peugeot	406R Coupe		AUTORADIO	Radio	√	√	√	√	√	
Peugeot	406R Coupe		COMBINE_VDO	Instrument panel	√	√	√	√	√	
Peugeot	406R Coupe		COMBINE_VDO1	Instrument panel	√	√	√	√	√	
Peugeot	406R Coupe		SIEGE_BITRON	Seat and mirrors with memory	√	√	√	√		
Peugeot	406R Coupe			Alarm	√	√	√			
Peugeot	406R Coupe		DVA_Z	Power Steering	√	√	√			
Peugeot	406R Coupe			CD player On-board	√	√	√	√	√	
Peugeot	406R Coupe			navigation system	√	√	√	√		
Peugeot	406R Coupe			Diesel fuel additive control unit	√	√	√	√		
Peugeot	406R Coupe			Rain/brightness sensor	√	√	√			
Peugeot	BOXER 3		4HU PUMA DCU102	Engine	√	√	√	√	√	
Peugeot	BOXER 3		4HV PUMA DCU102	Engine	√	√	√	√	√	
Peugeot	BOXER 3		Sofim 3.0 145cv	Engine	√	√	√		√	

Peugeot	BOXER 3		Sofim 3.0 145cv FAP	Engine	✓	✓	✓		✓	
Peugeot	405		LFZ SAGEM S2000	Petrol Engine	✓	✓	✓	✓		
Peugeot	405		1600RD SAGEM S2000	Petrol Engine	✓	✓	✓	✓		
Peugeot	405		N6A ME7.4.4	Petrol Engine	✓	✓	✓	✓	✓	Initialising the autoada ptives
Peugeot	405		N6B ME7.4.4	Petrol Engine	✓	✓	✓	✓	✓	Initialising the autoada ptives
Peugeot	405		NFU ME7.4.4	Petrol Engine	✓	✓	✓	✓	✓	Initialising the autoada ptives
Peugeot	405		LFY BOSCH MP7.3	Petrol Engine	✓	✓	✓	✓		
Peugeot	1007 VAN		NFU ME744	Petrol Engine	✓	✓	✓	✓	✓	Initialising the autoada ptives
Peugeot	1007 VAN		N6A BOSCH ME7.4.5	Petrol Engine	✓	✓	✓	✓	✓	Initialising the autoada ptives
Peugeot	1007 VAN		N6B BOSCH ME7.4.5	Petrol Engine	✓	✓	✓	✓	✓	Initialising the autoada ptives
Peugeot	1007 VAN		NFU BOSCH ME7.4.5	Petrol Engine	✓	✓	✓	✓	✓	Initialising the autoada ptives
Peugeot	1007 VAN		KFV S2000PM2	Petrol Engine	✓	✓	✓	✓	✓	
Peugeot	1007 VAN		KFU MM6LP	Petrol Engine	✓	✓	✓	✓		
Peugeot	1007 VAN		KFV J34P	Petrol Engine	✓	✓	✓	✓	✓	
Peugeot	1007 VAN		8HX SIEMENS SID 804	Diesel Engine	✓	✓	✓	✓		
Peugeot	1007 VAN		8HZ SIEMENS SID 804	Diesel Engine	✓	✓	✓	✓		
Peugeot	1007 VAN		Controlled manual gearbox(BVMP)	Auto gearbox	✓	✓	✓		✓	
Peugeot	1007 VAN			Alarm ALARME	✓	✓	✓	✓	✓	
Peugeot	1007 VAN			Radio RD3	✓	✓	✓	✓	✓	
Peugeot	1007 VAN			Built-in system interface(BSI)	✓	✓	✓	✓		
Peugeot	1007 VAN			ABS	✓	✓	✓	✓	✓	Bleeding
Peugeot	1007 VAN			Instrument panel	✓	✓	✓	✓		
Peugeot	1007 VAN			Steering wheel switching module	✓	✓	✓	✓		
Peugeot	1007 VAN			Airbags	✓	✓	✓	✓		
Peugeot	1007 VAN			Air Conditioning	✓	✓	✓	✓		
Peugeot	1007 VAN		Multi-function display EMF	Display/Telematics	✓	✓	✓	✓	✓	
Peugeot	1007 VAN			Parking assistance	✓	✓	✓	✓		
Peugeot	1007 VAN			CD player	✓	✓	✓	✓		
Peugeot	1007 VAN			Rain/brightness sensor	✓	✓	✓			
Peugeot	1007 VAN			Sliding side doors module	✓	✓	✓	✓		
Peugeot	207		5FW MEV17.4	Petrol Engine	✓	✓	✓	✓	✓	
Peugeot	207		8FS MEV17.4	Petrol Engine	✓	✓	✓	✓	✓	
Peugeot	207		MM6LPB	Petrol Engine	*	*	*	*	*	
Peugeot	207		NFS BOSCH ME7.4.5	Petrol Engine		*	*	*	*	
Peugeot	207		NFU BOSCH ME7.4.5	Petrol Engine		*	*	*	*	
Peugeot	207		MK70.1	ABS	✓	✓	✓	✓	✓	
Peugeot	207 Diesel		9HX BOSCH EDC 16C3 Common Rail	Engine		✓	✓	✓	✓	1.EGR throttle learning

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

Peugeot	207 Diesel		9HZ BOSCH EDC 16C34 Common Rail	Engine		✓	✓	✓	✓	1.EGR throttle learning
Peugeot	207 Diesel		8HZ BOSCH EDC 16C3 Common Rail	Engine		✓	✓	✓	✓	
Peugeot	207 Diesel		9HX BOSCH EDC 16C34 (K-LINE)	Engine		*	*	*	*	*1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	207 Diesel		9HZ BOSCH EDC 16C34 (K-LINE)	Engine		*	*	*	*	*1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	207		A/T AM6	AT		✓	✓	✓	✓	
Peugeot	207			ABS		✓	✓	✓	✓	
Peugeot	207			Airbag		✓	✓	✓		
Peugeot	207			Steering column module		✓	✓	✓	✓	
Peugeot	207			SERVICE LIGHT RESET						1.Service Reset
Peugeot	207			Parking brake		*	*	*		

Peugeot	407	1.6 16v HDI	9HY BOSCH EDC 16C34 (CANBUS)	Engine		*	*	*	*	*1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	407	1.6 16v HDI	9HY BOSCH EDC 16C34 (K-LINE)	Engine		*	*	*	*	*1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	407	1.6 16v HDI	TRW Autoliv AirBag	AIRBAG		√	√	√		
Peugeot	407	1.6 16v HDI	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		√	√	√	√	
Peugeot	407	1.6 16v HDI	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		*	*	*	*	
Peugeot	407	1.6 16v HDI		Steering column module		√	√	√	√	
Peugeot	407	1.6 16v HDI	A/T AM6	AT		√	√	√	√	
Peugeot	407	1.6 16v HDI		ICM		√	√	√	√	
Peugeot	407	1.6 16v HDI	Clima	Air Condition		*	*	*		
Peugeot	407	1.6 16v HDI		Parking brake		*	*	*		
Peugeot	407	1.6 16v HDI	K-LINE	Diesel addition		*	*	*	*	
Peugeot	407	1.6 16v HDI	CANBUS	Diesel addition		*	*	*	*	
Peugeot	407	1.6 16v HDI		SERVICE LIGHT RESET						*1.Service Reset
Peugeot	407	1.6 16v HDI FAP	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		√	√	√	√	



Peugeot	407	1.6 16v HDI FAP	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		*	*	*	*	
Peugeot	407	1.6 16v HDI FAP	BOSCH EDC 16C34 [9HZ]	ENGINE		√	√	√	√	1.EGR SV learning 2.EGR throttle initial. and intake air heat.
Peugeot	407	1.6 16v HDI FAP	9HY BOSCH EDC 16C34 (K-LINE)	Engine		*	*	*	*	*1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	407	1.6 16v HDI FAP		Steering column module		√	√	√	√	
Peugeot	407	1.6 16v HDI FAP	A/T AM6	AT		√	√	√	√	
Peugeot	407	1.6 16v HDI FAP	TRW Autoliv AirBag	AIRBAG		√	√	√		
Peugeot	407	1.6 16v HDI FAP		ICM		√	√	√	√	
Peugeot	407	1.6 16v HDI FAP	Clima	Air Condition		*	*	*		
Peugeot	407	1.6 16v HDI FAP		Parking brake		*	*	*		
Peugeot	407	1.6 16v HDI FAP	K-LINE	Diesel addition		*	*	*	*	
Peugeot	407	1.6 16v HDI FAP	CANBUS	Diesel addition		*	*	*	*	
Peugeot	407	1.6 16v HDI FAP		SERVICE LIGHT RESET						*1.Service Reset
Peugeot	407	1.8 16v	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		√	√	√	√	
Peugeot	407	1.8 16v	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		*	*	*	*	
Peugeot	407	1.8 16v	MARELLI MPI MM6LPB [6FY]	ENGINE MANAGEMENT		√	√	√	√	

Peugeot	407	1.8 16v	TRW Autoliv AirBag	AIRBAG		✓	✓	✓		
Peugeot	407	1.8 16v		Steering column module		✓	✓	✓	✓	
Peugeot	407	1.8 16v	A/T AM6	AT		✓	✓	✓	✓	
Peugeot	407	1.8 16v		ICM		✓	✓	✓	✓	
Peugeot	407	1.8 16v	Clima	Air Condition		*	*	*		
Peugeot	407	1.8 16v		Parking brake		*	*	*		
Peugeot	407	1.8 16v		SERVICE LIGHT RESET						*1.Service Reset
Peugeot	407	2.0 16v	TRW Autoliv AirBag	AIRBAG		✓	✓	✓		
Peugeot	407	2.0 16v	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		✓	✓	✓	✓	
Peugeot	407	2.0 16v	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		*	*	*	*	
Peugeot	407	2.0 16v	MARELLI MPI MM6LPB [RFJ]	ENGINE MANAGEMENT		✓	✓	✓	✓	
Peugeot	407	2.0 16v		Steering column module		✓	✓	✓	✓	
Peugeot	407	2.0 16v	A/T AM6	AT		✓	✓	✓	✓	
Peugeot	407	2.0 16v		ICM		✓	✓	✓	✓	
Peugeot	407	2.0 16v	Clima	Air Condition		*	*	*		
Peugeot	407	2.0 16v		Parking brake		*	*	*		
Peugeot	407	2.0 16v		SERVICE LIGHT RESET						*1.Service Reset
Peugeot	407	2.0 16v HDI	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		✓	✓	✓	✓	
Peugeot	407	2.0 16v HDI	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		*	*	*	*	
Peugeot	407	2.0 16v HDI	TRW Autoliv AirBag	AIRBAG		✓	✓	✓		
Peugeot	407	2.0 16v HDI		Steering column module		✓	✓	✓	✓	
Peugeot	407	2.0 16v HDI	A/T AM6	AT		✓	✓	✓	✓	
Peugeot	407	2.0 16v HDI		ICM		✓	✓	✓	✓	
Peugeot	407	2.0 16v HDI	Clima	Air Condition		*	*	*		

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

Peugeot	407	2.0 16v HDI		Parking brake		*	*	*		
Peugeot	407	2.0 16v HDI	K-LINE	Diesel addition		*	*	*	*	
Peugeot	407	2.0 16v HDI	CANBUS	Diesel addition		*	*	*	*	
Peugeot	407	2.0 16v HDI		SERVICE LIGHT RESET						*1.Service Reset
Peugeot	407	2.0 16v HDI FAP	SIMENS HDI SID803A[RHR](K-LINE)	Engine		*	*	*	*	*1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	2.0 16v HDI FAP	SIMENS HDI SID803A[RHR](CANBUS)	Engine		*	*	*	*	*1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	2.0 16v HDI FAP	SIMENS HDI SID803A[RHL](K-LINE)	Engine		*	*	*	*	*1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	2.0 16v HDI FAP	SIMENS HDI SID803A[RHL](CANBUS)	Engine		*	*	*	*	*1.Particle filter regeneration 2.Replace or fill additive tank 3.Replace metering pump
Peugeot	407	2.0 16v HDI FAP	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		√	√	√	√	
Peugeot	407	2.0 16v HDI FAP	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		*	*	*	*	
Peugeot	407	2.0 16v HDI FAP	TRW Autoliv AirBag	AIRBAG		√	√	√		
Peugeot	407	2.0 16v HDI FAP		Steering column module		√	√	√	√	
Peugeot	407	2.0 16v HDI FAP	A/T AM6	AT		√	√	√	√	
Peugeot	407	2.0 16v HDI FAP		ICM		√	√	√	√	
Peugeot	407	2.0 16v HDI FAP	Clima	Air Condition		*	*	*		
Peugeot	407	2.0 16v HDI FAP		Parking brake		*	*	*		
Peugeot	407	2.0 16v HDI FAP	K-LINE	Diesel addition		*	*	*	*	

Peugeot	407	2.0 16v HDI FAP	CANBUS	Diesel addition		*	*	*	*	
Peugeot	407	2.0 16v HDI FAP		SERVICE LIGHT RESET						*1.Service Reset
Peugeot	407	2.2 16v HDI	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		√	√	√	√	
Peugeot	407	2.2 16v HDI	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		*	*	*	*	
Peugeot	407	2.2 16v HDI	TRW Autoliv AirBag	AIRBAG		√	√	√		
Peugeot	407	2.2 16v HDI		Steering column module		√	√	√	√	
Peugeot	407	2.2 16v HDI	A/T AM6	AT		√	√	√	√	
Peugeot	407	2.2 16v HDI		ICM		√	√	√	√	
Peugeot	407	2.2 16v HDI	Clima	Air Condition		*	*	*		
Peugeot	407	2.2 16v HDI		Parking brake		*	*	*		
Peugeot	407	2.2 16v HDI	K-LINE	Diesel addition		*	*	*	*	
Peugeot	407	2.2 16v HDI	CANBUS	Diesel addition		*	*	*	*	
Peugeot	407	2.2 16v HDI		SERVICE LIGHT RESET						*1.Service Reset
Peugeot	407	2.2 16v HDI FAP	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		√	√	√	√	
Peugeot	407	2.2 16v HDI FAP	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		*	*	*	*	
Peugeot	407	2.2 16v HDI FAP	TRW Autoliv AirBag	AIRBAG		√	√	√		
Peugeot	407	2.2 16v HDI FAP		Steering column module		√	√	√	√	
Peugeot	407	2.2 16v HDI FAP	A/T AM6	AT		√	√	√	√	
Peugeot	407	2.2 16v HDI FAP		ICM		√	√	√	√	
Peugeot	407	2.2 16v HDI FAP	Clima	Air Condition		*	*	*		

Peugeot	407	2.2 16v HDI FAP		Parking brake		*	*	*		
Peugeot	407	2.2 16v HDI FAP	K-LINE	Diesel addition		*	*	*	*	
Peugeot	407	2.2 16v HDI FAP	CANBUS	Diesel addition		*	*	*	*	
Peugeot	407	2.2 16v HDI FAP		SERVICE LIGHT RESET						*1.Service Reset
Peugeot	407	3.0 24v	TEVES ABS MK60 (CANBUS)	ABS + TRACT. CONTROL		√	√	√	√	
Peugeot	407	3.0 24v	TEVES ABS MK60 (K-LINE)	ABS + TRACT. CONTROL		*	*	*	*	
Peugeot	407	3.0 24v	TRW Autoliv AirBag	AIRBAG		√	√	√		
Peugeot	407	3.0 24v		Steering column module		√	√	√	√	
Peugeot	407	3.0 24v	A/T AM6	AT		√	√	√	√	
Peugeot	407	3.0 24v		ICM		√	√	√	√	
Peugeot	407	3.0 24v	Clima	Air Condition		*	*	*		
Peugeot	407	3.0 24v		Parking brake		*	*	*		
Peugeot	407	3.0 24v		SERVICE LIGHT RESET						*1.Service Reset
Peugeot	PARTNER 2		BOSCH ME 7.4.5	Engine		√	√	√	√	
Peugeot	PARTNER 2		9HW BOSCH EDC 16C34	Engine		*	*	*	*	*1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling 9.Particle filter regeneration
Peugeot	PARTNER 2		BOSCH ABS 8.1	ABS		√	√	√	√	
Peugeot	PARTNER 2			Airbag		√	√	√	√	

<http://www.autoboss.net>

<http://www.servicesolutions.com.cn>

Peugeot	PARTNER 2			SERVICE LIGHT RESET						*1.Service Reset
Peugeot	308		BOSCH EDC 16C34	Engine		✓	✓	✓	✓	1.EGR SV learning 2.EGR throttle learning 3.Initialization turbo limit 4.Particle filter replacement 5.Initializ. FAP filter additive quantity 6.Replace or fill additive tank 7.Replace metering pump 8.Tank filling *9.Particle filter regeneration
Peugeot	308		BOSCH ABS 8.0	ABS		✓	✓	✓	✓	1.Steering angle calibration 2.Brake air bleed
Peugeot	308		TRW Autoliv AirBag	Airbag		✓	✓	✓	✓	
Peugeot	308			ICM		✓	✓	✓	✓	
Peugeot	308			Steering column module		✓	✓	✓	✓	
Peugeot	308			SERVICE LIGHT RESET						1.Service Reset